

Set up Wi-Fi network:

Notices for Network Setting:

1. Mobile phones need to be operated with WIFI
2. Local WiFi connection recommendation should not exceed 10 devices
3. It is not possible to use the 5GWiFi network. It needs to operate at 2.4 GHz network frequency.
4. When installing, you need to give the mobile APP network location permission.
5. Printers need to be connected in a good network environment (mobile WIFI interface can be used to check whether the network environment is generally above)
6. WiFi name cannot be used in Chinese
7. If you have any questions about the printer, please contact us. Our email address is: support@weefun3d.com

Method 1. Using the APP distribution network

Download the Andriod APP-Poloprint1.3.1 for the first time

App download: [External Link](#)

After the download is completed, the installation is completed. After the installation is completed, the first time the application is opened, the interface is displayed. The wizard interface is an introduction to the use of instructions on the app. The specific usage requires a tutorial corresponding to the specific model. This tutorial is for Tina2

Step 1: Enter the WIFI password in the network where the mobile APP brush WIFI settings interface (do not click OK first)