

— **Instruction Manual** —

BA803 ADPT



Customer Service
(800) 247-7668

Adapter for 46A Backboard

PARTS LIST					
Item	Qty	Description	Item	Qty	Description
A	1	BA803 Adapter Brackets (1 Left & 1 Right)	B	4	5/16" X 2 1/2" Hex Bolt
C	4	1/4" X 1 1/4" Special Bolt (BAACRYLIC)	D	4	1/4" Flange Nut (BAACRYLIC)
E	1	Backboard	F	1	Backboard Support Plate (BA803 Instruction Item O)

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
- ◆ Read all instructions before proceeding.

Note:
Refer to the BA803 instructions for Base Assembly prior to Backboard Installation.

Note:
The 5/16" X 3 1/2" Carriage Bolts (H) included in the BA803 Hardware are not used for this application.

1. Using the 1/4" X 1 1/4" Special Bolts (C) and the 1/4" Flange Nuts (D) bolt the BA803 Adapter Brackets (A) to the Backboard (E). Leave bolts finger tight. See illustration on page 2 for correct orientation of the BA803 Adapter Brackets (A).
2. Bolt the Backboard (E) assembly to the Adjustable Poles (Item (D), BA803 Hardware) using the 5/16" X 2 1/2" Hex Bolts (B), 5/16" Flat Washers (Item (I), BA803 Hardware), 5/16" Lock Washers (Item (J), BA803 Hardware), and the 5/16" Hex Nuts (Item (K), BA803 Hardware). See Illustration on page 2.
3. Tighten all hardware.

Note:
Refer to the BA803 instructions to finalize assembly.

