

# Express Care Kit

## Application Instructions

### Application Instructions

- 1 Start by wetting the glass and using the white scrubber pad with Restoration Powder™ (just a light touch) to remove any stains. If stains persist, use more pressure, but not so much as to damage the DFI coating.
- 2 Once thoroughly clean and dry, apply the Revitalizer™ protective coating in a well-ventilated area, using firm circular, overlapping motions, going over the entire area at least twice. Only unfold the towelette as needed.
- 3 To test the application, spray the glass with water and look for uniform water beads. For areas that are not beading up uniformly, dry the entire surface and reapply the Revitalizer™ coating as needed.
- 4 Finalize the application process by either polishing the glass with the microfiber towel or washing with soapy water.

### Important:

It is recommended to test a small amount of Restoration Powder™ on an inconspicuous area before use to ensure compatibility. Not for use on lacquered surfaces.

