

Glass Defender™ Kit

Application Instructions

Application Instructions

- 1 Start by wetting the glass and using the white scrubber pad with Restoration Powder™ to remove any stains. If stains persist, use more pressure.
- 2 Once thoroughly clean and dry, apply Clear-Fusion™ V protective coating in a well-ventilated area. Spray the coating as needed and wipe with the microfiber towel using firm circular, overlapping motions, going over the entire area at least twice.
- 3 To test the application, spray the glass with water and look for uniform water beads. For areas that are not beading up uniformly, reapply Clear-Fusion™ V as needed.

Important:

When applying Clear-Fusion™ V to the glass, we recommend approximately four (4) full sprays for each square foot of glass being treated.

Important:

Make sure the microfiber towel is completely dry when wiping in the coating.

Important:

In less-ventilated areas, apply Clear-Fusion™ V coating in small sections.

