

## Glass Rescue™ Application Instructions

## **Application Instructions**

- Start by wetting the surface as needed and apply Glass Rescue™ with a non-abrasive nylon pad, using circular motions. If you do not have a non-abrasive nylon pad, we recommend using our white scrubber pad with handle. If stains persist, use more pressure.
- Thoroughly rinse any residue and dry glass after for optimum performance.

## **Important:**

It is recommended to test a small amount of Glass Rescue™ on an inconspicuous area before use to ensure compatibility. Not for use on lacquered surfaces.

## **Important:**

When using the Glass Rescue™ Bottle, please shake the contents before using, and keep the cap tightly closed to prevent drying out.

