

Revitalizer™

Application Instructions

Application Instructions:

- 1 Clean and dry the surface that is to be treated – the cleaner the surface, the better the coating.
- 2 Once thoroughly clean and dry, apply the Revitalizer™ protective coating in a well-ventilated area. Spray the coating as needed and wipe with the microfiber towel using firm circular, overlapping motions, going over the entire area at least twice.
- 3 Remove any excess solution by sprinkling the glass with water and wiping the surface with a clean dry cloth or paper towel until glass is clear and sparkling.
- 4 Reapply the coating as needed or when water repellency begins to wane.

Important:

For Revitalizer™ NanoPax® applications, use firm circular, overlapping motions, going over the entire surface at least twice and only unfold the towelette as needed.

Important:

If the glass to be treated is heavily stained, DFI recommends using our Express Care Kit or Restoration Powder™, along with a scrubber pad, to remove any stains and prep the surface for the Revitalizer™ coating application.

Important:

In less-ventilated areas, apply Revitalizer™ treatment in small sections.

