## GRANDIN ) TE MAGNETOSOLID® AMPLIFIERS



# GRANDINOTE SILVA

### USER MANUAL

PAG. 1 DI 8



#### INDEX

- INTRODUCTION PAG. 3
- PRODUCT DESCRITION PAG. 3
  - SPECIFICATIONS PAG. 4
    - WARNINGS PAG. 5
- CONNECTIONS REAR PANEL PAG. 6
  - FRONT PANEL PAG. 7

#### INTRODUCTION

**GRANDINOTE** congratulates with you for the excellent choice done, buying this exclusive amplifier, masterpiece of style and technology.

You listened the extraordinary musical caracteristics of "Magnetosolid®" amplifiers: neutral tone, rich details and harmonics, high speed, big extension, big tight.... without intermodulation distortion, with surprising dynamic range, insuperable coherence, natural sound...

These and other qualities are the result of studies and extensive research about the union and interaction of **solid** state components with ferro**magnetic** machines.

The fusion of the words: "**Magnetic**" and "**Solid**" is the born of "**Magnetosolid**®", the point of union of all amplifiers by Grandinote.

#### PRODUCT DESCRITION

**GRANDINOTE SILVA** is a full-balanced and full-dualmono monofonic power amplifier.

Grandinote Silva by **Magnetosolid**® technology claim musical qualities of tight and extension like solid state amplifier, preserving musicality, sweetly and naturality like valuable tube amplifier.

#### SPECIFICATIONS

- Full-dualmono power amplifier
- Power for channel 37W (4 and 8 Ohm)
- Damping factor >150
- Frequency response 2Hz 280 kHz
- One balanced input XLR (full-balanced)
- Tensione d'ingresso di saturazione 750mV RMS
- Class "A"
- Direct coupling stages: without capacitors between stages
- No feedback
- Weight 40kg
- W=318 x H=196 x L=473 [mm]
- Voltage power supply 230V
- Absorption 270W
- Magnetosolid® Technology

#### NOTE:

These specifications will can change without the obligation to report, by Grandinote.

#### WARNINGS

For the correct and sure use of this product, Grandinote recommends the study and the application of this warning list.

- Don't open the device.
- Don't turn off and turn on quickly the device.
- Before connecting/disconnecting cables, turn off the device and wait one minute.
- In case of malfunction, contact Grandinote's assistance.
- Don't close the vents of cooling of the device.
- Don't put objets or liquids in the vents of cooling of the device.
- Keep clean the alluminium dissipators with compres air, or contact Grandinote's Assistance.
- Have care the device is supported by correct stand, in functio of the weight of the device specificated in this user manual.
- Don't strike and don't shake the device.
- Temperature range from to 0°C to 35°C.
- Don't approach the device to water, acid, or dangerous substances.
- Don't put every object on the device.
- Clean only with a dry cloth, or slightly damp with water and neutral soap.
- Be sure the power supply net is correct with the device's specifications.
- Be sure the electrical load, on the output connectors, has the correct specifications for the device.
- Don't be short circuit between the connectors with other connectors, ground, the device's body or other potentials.
- Connect the inputs audio, only to appropiate and properly functioning audio sources.
- Don't put potentials or currents not appropiate in the device's inputs, only "LINE" signals.
- Handle the device with care, for don't damage it, or other things or persons.
- Use the device only for audio amplification and not for other applications.
- Keep the device away from pets, child or other people, who with a inappropriate use can cause damage.

#### If you don't hear any sound,

using speaker wires with fork connectors,


check that the fork connectors make contact with the gold parts of the output connectors of the device.

#### **CONNECTIONS - REAR PANEL**

In the **PICTURE 2**, we see the device's input-output connectors.

Input connectors, called **IN**, are balanced XLR (full balanced).

In the external of the picture, in the half, we see the output loudspeakers connectors, in the lower we see the IEC connectors for the power supply, for each channel. The protection fuses are inside this connectors.



#### PICTURE 2: REAR PANEL

#### FRONT PANEL

In the **PICTURE 3**, we see the device's front panel. The ON/OFF led is in the middle of panel, below it the power supply switch. (Don't turn off and turn on quickly the device)



PICTURE 3: FRONT PANEL



GRANDINOTE SRLS VIA PRIMO MAGGIO, 32 27042 BRESSANA BOTTARONE (PV) -ITALY-

P.IVA: 02659140186 COD. FISCALE: 02659140186 COD. IBAN: IT12B083868380000000382064 BIC/SWIFT: ICRAITRRAQ0

WWW.GRANDINOTE.IT GRANDINOTE@GMAIL.COM

WWW.FACEBOOK.COM/GRANDINOTE