



EZGO TXT / Medalist Seat Set Installation Guide


Tools Needed

- Clean Workspace
- Socket Wrench
- Safety Glasses
- Drill w/ Phillips Head Bit

NOTES:

To ensure a clean seat installation, use soap and warm water to remove any dirt build up from your hip restraints and back rest cover (optional) before mounting to your new seat cushion.

Prior to install, verify that your existing bolts are in good enough condition to use with new seats. If new bolts are needed, replace with stainless 1/4"-20 machine screws. To avoid cross threading or stripping of fasteners, always start each bolt by hand



Old Seat Removal

- Detach the back rest from the cart frame by removing the 4 back rest bolts. Set bolts and washers aside for installation.
- Pull your seat cushion forward and lift away from the hinge receivers on the cart. Detach each hip restraint and seat hinge from the seat by removing each bolt. Set all components (bolts included) aside for installation with the new cushion.

Seat Hinges

Starting with the driver side, align seat hinge with triangular pilot hole pattern on the seat board. Hand tighten hinge screw in each hole to ensure proper placement. Complete the mounting process by driving each screw with your drill. Repeat step for passenger side seat hinge.




Hip Restraints

Line up the short restraint (driver's side) with the hole pattern on the new seat board. Using original restraint bolts, hand tighten the 2 innermost bolts (circled) then use your socket wrench to fasten bolts completely. This helps to align the bolt holes on the outer edge, making it easier to drive the final 2 bolts. Hand tighten then use your socket wrench to complete the driver's side restraint installation. Repeat step for long restraint (passenger's side).



Seat Cushion

After hinges and restraints are mounted to your seat cushion, you're ready to place on your golf cart. Line each hinge up with the receiver brackets on the cart and place into the slots. Gently lower the cushion so that the seat folds down.



Back Rest

NOTE: Back rest has been finished with a black vinyl panel and can be installed without factory back cap. (Torino seat not compatible with back cap)
Place washer on each back rest bolt prior to inserting into cart frame. Start with top left bolt hole, and place bolt into frame. Bring back rest cushion to bolt and hand tighten. Repeat for bottom right bolt hole and again for top right and bottom left. Once all 4 bolts have been set, complete mounting process with socket wrench.