

2x/3x/5x/6x Magnified LED Lit Head Visor

Congratulations on selecting your new Smartphone Telescope Adapter! In order to achieve optimum performance, please follow instructions for proper use and care.




PRODUCT SPECIFICATIONS

Magnification:	2x/3x/5x/6x	Dimensions:	7.6" x 3.2" x 10.4"
Weight:	0.41 lbs	Battery:	3 AAA (not included)

CHOOSING DESIRED MAGNIFICATION


1. Use lens chart below to determine which lens combination will produce your desired magnification. See Figure to determine lens number.
2. To use Lens 2, swing the lens down until it clicks into place directly behind Lens 1.
3. To use Lens 3, rotate the lens until it is positioned in front of Lens 1.

Lens Combination	Magnification
Lens 1 only	2x
Lens 1 and Lens 2	3x
Lens 1 and Lens 3	5x
Lens 1, Lens 2 and Lens 3	6x



INSTALLING BATTERIES

Located behind LED lamp, remove battery door and battery case from compartment. Insert 3 AAA batteries into battery case according to correct polarity indicated on top and bottom of case. Replace battery case and close battery door when finished.




WARNING

Use only alkaline batteries. Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Rechargeable batteries not recommended.

ADJUSTING HEAD STRAP


1. Press down on buckle marked "push" to release strap lock.
2. Adjust strap to desired size.
3. Release buckle to lock strap in place.



USING MAGNIFIER

Once placed on your head, the visor can be adjusted up or down as needed. Adjust the lens to the desired viewing angle.

To activate LED lights, slide switch on top of visor to turn ON/OFF.



CLEANING/CARE

- Handle lenses with care to avoid scratching. Always store item in box when not in use.
- Clean using microfiber lens cloth only. Do not use any abrasives, chemical cleaners or solvents.
- Do not use outdoors when in direct sunlight. Do not store product in any area exposed to direct sunlight.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, **visit www.carson.com/warranty**

www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000