


QIK RETROFIT™

LWQR 2X2 -30W-W4000K (4,050 Lumens) - 2 strips

LWQR 2X2 -40W-W4000K (5,400 Lumens) - 3 strips

LWQR 2X4 -40W-W4000K (5,400 Lumens) - 2 strips



QIK RETROFIT™

Parts List

PCB Strips

A




Input / Line Voltage

B




Magnetic quick connect clips

C



Driver with w/magnetic quick connect clips

D



QIK RETROFIT™

Installation directions

WARNING : Turn OFF electricity at the junction box before any installation.

Each kit is **specified to your requirements** . The kits are configured with the PCB Strips and the driver and **should never be changed or altered in any way** .

Each kit come with: (see page 2)

PARTS

- **A** 2 or 3 PCB strips.
- **B** 1 driver with a quick connect to mount to the harness of the PCB.
- **C** magnetic clips.
- **D** the appropriate amount of harness for the driver.

INSTRUCTIONS

- 1 take out the old fluorescent tube.
(it is best to disconnect tomb stones/lamp holders).
- 2 cut the line voltage wire going to the driver.
- 3 using the quick connect(if purchased) (otherwise use wire nuts), connect the line voltage to the driver line voltage wires.

QIK RETRoFIT™

QIK RETRoFIT diagram

