ASSEMBLY INSTRUCTIONS


Model 2-230

Rolling Work Seat with Spinning GearTray



1


Using an T40 TORX 6 lobe star key wrench, attach four casters to the X-Frame using the four lock washers and barrel nuts.



IMPORTANT

Very Important that the lock washer is compressed completly flat.

Slide the pnematic cylinder into the X-Frame drop sleeve. Slide the spinning Gear Tray onto the cylinder.





Mount seat base onto the bottom of the seat using four washers and bolts.

Slide the seat base onto the top of the pneumatic cylinder. Frame, cylinder and seat will all press fit together.



Adjusting the Seat Height

While sitting on the seat pull up on the height adjustment lever to lower the seat height. To raise the seat lift your weight off the seat and pull up on the lever.



This product has features that are patent pending.

Please contact us if you have any questions or comments and thank you for choosing TraXion!

517 South 28th Street; Van Buren, AR 72956