



**Dear Customer,**

We would like to congratulate on your purchase, we are doing our best to provide you with top quality products and services.

We are here to answer any question you may have.

This manual has been created to walk you through assembling your new car mount for the first time.

**Sincerely**

**Bestrix Team**





## **Bestrix CH 9080 Car Mount**



### **INSTALLATION GUIDE**

Bestrix CH 9080 Car Mount provides extra convenient smartphone mounting capabilities in vehicles for most types of cup holders.

Bestrix CH 9080 Car Mount can be easily installed on most cup holder and is compatible with all different smartphones types including all iPhones and Android devices. (Please note – Does not support Pop Socket and thick cases such as Otterbox, LifeCase, Battery Case, Mophie Case etc.)

1. Insert the cradle into the cradle holder and push it upward until you will hear a "click".



push to lock



**Important! Please make sure that the cradle is locked properly to the base before installing it in the car.**

2. In the back of the cradle you have 2 buttons, the upper one is to release the grips and the bottom one is to open the cradle adjustable support legs for full length (for large screen).



- 3. A.** The adjustable base in the bottom part of the mount is used to lock the device in place.



**B.** Place the adjustable base in the cup holder and turn the adjustable base clockwise to lock the base into the cup holder and counter clockwise to release it.



4. Adjust the flexible gooseneck with your preferred Height and angle for easy phone access.

Place the phone inside the cradle and gently squeeze the grips together. To remove your phone push gently the upper button on the back side of the cradle to release the grips.



5. The adjustable cradle allows you to set your phone in both landscape and portrait view.



**ENJOY**

If you have any question you can contact us at:  
[support@bestrix.com](mailto:support@bestrix.com)

[www.bestrix.com](http://www.bestrix.com)