





Little Martin's Electric Bidet

User Manual

For Model BEB1706





Warranty Certificate

This certificate promises our customers that they will receive free repair. If you notice any problems listed below within the warranty period, please contact our customer service with this certificate.

- Once you have used this product, we basically will not offer exchange.
- When the product is damaged (after proper use) within the warranty period which is a year from the purchase date, we will repair it for free. Contact us via email support@littlemartinsdrawer.com, and send the product over to our customer center.
- Even within the warranty period, in the following situation the repair process will come with a fee.
 - Natural discoloration of the plastic area.
 - Damage due to misuse of the product.
 - Damage due to fire, water, earthquake and other natural disasters.
 - Damage due to commercial or business usage.
 - The shipping fee for paid repair.
- This service will apply only inside United States.
- Once the product is out of production and certain parts are out of stock, we will not be able to offer certain repairs.



BATCH CODE
SEE THE LOT LABEL AT THE BOX
OF THE PACKAGE



CONSULT INSTRUCTIONS FOR USE



100% RECYCLEABLE



WASTE FROM
ELECTRICAL AND
ELECTRONIC
EQUIPMENT (WEEE)




Important

Be sure to clean and dry water reservoir after use. Ensure no water is left inside the waterpipe.

(TIP: Operate the bidet for a few seconds more after removing water reservoir)

Tips

Clean where and when as needed. Select from Strong or Soft Modes.



H: Strong Mode



L: Soft Mode



Turn waterpipe port 180° for complete cleaning



To save energy, bidet will turn off automatically when unused for 60 seconds.

Bidet is waterproof for easier cleaning.

Technical Specifications

Size	Φ 48 X160mm
Weight	215g
Reservoir Volume	140mL
Run Time(Soft Mode)	≥ 180 Times
Displacement(Soft Mode)	110mL/Minute
Run Time(Strong Mode)	≥ 120 Times
Displacement(Strong Mode)	150mL/Minute
Waterproof	IPX6
Noise	≥ 65dB
Working Output Current	< 200mA
Motor	DC 3.0V YYP370-3C2
Power Source	2 x AAA Battery
Working Mode	L Soft Mode-H Strong Mode



Cautions

- Bidet is intended for external use only.
- Avoid filling with water above 40°C.
- Clean bidet body, reservoir, and waterpipe regularly to prevent bacteria growth.
- For proper cleaning, use the bidet spray in a circular motion.
- Do not drop, knock, or apply force to the device.
- Do not detach or change any internal parts.
- Remove the battery if device is unused for a prolonged period.
- This product is not a toy and contains small parts not suitable for children under 5 years of age.