LTPRM-10 Set up Instructions

1) Unhook straps, remove lid and set out parts.



3) Unfold frame.



5) Secure all four sets of lock pins.



7) Lock all four corner supports.



2) Remove frame from case.



4) Connect frame together at all four center points.



6) Attach both side supports.



8) Pull pins and lock both feet into place.



9) Connect top and bottom center light connections.



10) Using the longest of the three white light cords connect to the light connection at the top right of the frame.

11) Run the long cord along the inside of the right side of the frame and connect to the round side connection points.


If connection points are not on the frame add them from the bag of extra parts that comes with your order.

12) At the bottom of the right side connect the long cord to one of the short light cords and feed through the corner of the frame. This will connect to a power supply later.









13) Using the remaining short light cord connect to the light connection at the bottom right of the

frame. Feed through the corner of the frame. This will connect to a power supply later.



14) Light cords should feed through the same

frame corner and connect to power supplies after the frame is set into place.



15) Lay out blocker and attach to frame with SEG starting at corners, middle then all sides.






16) Flip frame over and attach graphic to front of frame with SEG starting at corners, middle then all sides.





17) Stand frame up and put into place. Connect light cords to both power supplies.







Plug in power supplies to turn the Pliko frame on.