





# Ergonomic Corporation (Hong Kong) Ltd.

## CP-2 IPAD / TABLET & LAPTOP CHARGING CART

- 32/36/40 ipads/ tablet or laptops capacity options.
- Dimensions 1130\*580\*950mm approx.
- Cooling vent on both front and rear doors for air circulation purpose.
- 5" Smooth rolling wheels with brake locks to provide added control and portability.
- The handle customer for moving the cart.
- Room provided on the top shelf for a work platform or for use with printers, projectors, and scanners.
- Drawer (retractable ) provided in cart.
- Power sequencer for charging all laptops through power cycling and give charge one by one in 1 second and power switch for power protector (basically for protection of tablets ) ,and smart timer for setting charging time.



**Ventilation**  
Ventilation holes allows for maximum air flow within the cart & prevent from Overheating.

**Extra Space**  
Cart features a large working surface (top of the cart) to support an extra laptop & printer.

**One Power Cord**  
Single grommet hole & cord enables cart to be plugged into wall for easy charging of laptops.



Very popular in schools, collages, hospitals , offices (specially in conference rooms) & many other professional places.

### Smart Timer



The ACAT is designed to maximize your charging options by allowing you to set the duration needed for your specific application. OUTLETS A, B, C & D are Always On while OUTLETS 1, 2, 3 & 4 are controlled by adjusting the following:

**Constant Power for OUTLETS 1, 2, 3 & 4:**  
1) Move Mode Selection Switch to "Always On"  
2) Press the "Start / Stop" button  
Note: OUTLETS 1 through 4 turn ON and will remain ON until you press "Start / Stop" button again

**Timer Mode for OUTLETS 1, 2, 3 & 4:**  
1) Move Mode Selection Switch to "Timer Mode"  
2) Set the number of Minutes & press "Enter"  
3) Press the "Start / Stop" button  
Note: OUTLETS 1 through 4 turn ON for your specified time, then turn OFF

**Cycle Mode for OUTLETS 1, 2, 3 & 4:**  
1) Move Mode Selection Switch to "Cycle Mode"  
2) Set the number of Minutes & press "Enter"  
3) Press the "Start / Stop" button  
Note: OUTLET 1 will turn ON then turn OFF for your specified time, OUTLET 2 will do the same, as will OUTLET 3 & 4. The cycle will loop and repeat until you press the "Start / Stop" button again.



### RIFE TECHNOLOGIES

**Delhi Office:**  
362, Vardhman Plaza - II, J-Block, Community Centre, Rajouri Garden, New Delhi - 110027

☎ (011) 2516-7799, 2592-5555  
✉ sales@rifeindia.com  
🌐 www.rifeindia.com

**HongKong Office:**  
Ergonomic Corporation (Hong Kong ) Limited. 2nd floor Eton tower 8 , Hysen Avenue Causeway, Hongkong.

☎ 852 - 61819896  
✉ rishi@ergohongkong.com , ergohongkong@gmail.com  
🌐 www.ergohongkong.com