

INSTALL DIRECTION

MASSAGE BATHTUB

MODEL : WS-062



ANTIQUE TUB



Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

INSTALLATION

1. Fix shower head and pillow first.
2. Connect the drain hose to the cloaca.
3. Connect to the cool and hot water pipe.
4. Adjust the screw on the feet to make the bathtub horizontal.
5. Connect to power supply, then fill water to have a test.

Parameter

Voltage: 220-240V 50/60Hz Power: 1HP
Size: 1700x800x780mm

Operation

1. Fill water

Turn the cool/hot switch to adjust the water temperature, turn the shift switch to fill water through shower head or faucet or waterfall nozzle. Stop to fill water when the water level is 10-20mm above the spray nozzle.

2. Hydraulic massage

Press the pump switch to start the pump and Jacuzzi, and turn the air regulator to adjust the hydraulic power. Push the nozzle to change the water spray direction. Press the switch again to turn off the pump.

3. Shower

Turn the cool/hot water switch to get suitable temperature, then turn the shift switch to use shower head to take a shower.


4. Power off

Press the pump switch to turn off the pump, then turn the drain switch to let out the water, when stop use, turn off the power source switch and the water supply switch.

Attention

1. The rated power of this product is 220V 50Hz, please make sure not to overload it.
2. Make sure to fix leakage protection device, and the socket must be connected with earth line.
3. Please don't block the water recycle nozzle by any part of your body, if that occurs, turn off the pump or power at once.
4. A switch for the supply of the hot /cool water must be installed, when stop to use this product the water supply switch and the power source switch should be turned off.
5. Check the water level if it is 10-20mm above the spray nozzle before you start the pump or the pump could be damaged.
6. Don't use corrosive detergent to clean the bathtub, you could use common daily detergent or toothpaste to clean it.
7. Dispose of the product according to the local law when it is out of use.
8. Please contact the local dealer for help if you have any problem.

Sketch



Size: 1700x800x780mm