HB80-2

HB80-JAL

SERENE Glass Door Cooler



User Manual
MAN80030 Rev. 3.0 Nov. 2018

S C T C 11 C[®]

CONTENTS

1 Installation 2 Operation Cabinet Light6 3 Maintenance Condenser Coil9

Installation

Safety First Always observe safety precautions when using any electrical appliance. Read these instructions carefully and retain them for future reference.

- When the appliance is used by or near young children or infirm persons, close supervision is necessary, especially to ensure children do not play with it.
- Do not use this appliance for other than its intended use.
- Do **not** cover the grilles or block the entry or exhaust of airflow by placing objects up against the refrigeration system.
- Do not probe any opening.
- Only use this appliance with the voltage specified on the cabinet rating label affixed to the appliance.
- Ensure the appliance has adequate ventilation as this is essential to economical, high performance.
- Be careful not to touch moving parts and hot surfaces.
- For your own safety and that of others, ensure that all electrical work is done by authorised personnel.
- If the power supply flexible cord becomes damaged, it must be replaced by an authorised service agent or similarly qualified person in order to avoid a hazard.
- This appliance is not designed to be stable in motion. Use extreme caution when moving or transporting it.
- Ensure all necessary safety precautions are observed during installation or removal of the appliance.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Please contact SKOPE Customer Services for advice regarding disposal of this appliance.

- Warning Should defrosting be necessary, turn off the refrigeration system and allow the ice to melt by air circulation. Do not use mechanical methods to remove ice, as this may damage the refrigeration circuit.
 - Do not use any electrical appliances inside the food storage compartment.
 - Do not modify the appliance in any way.

CAUTION

Never overload the power supply, which could damage the cabinet and product. See the rating label inside the cabinet for the safe power supply and current draw.

WARNING

Always disconnect the cabinet from the mains power supply before cleaning or maintenance.



WARNING

The refrigeration system contains flammable R600a.

Installation User Manual

Unpacking

Remove all packing material from the inside and outside of the cabinet, including the foam base and all adhesive tape holding the cabinet accessories.

Shelves The cabinet is supplied with two shelves. Remove the packing material and then position the shelves into the cabinet at the desired heights. The bottom shelf has hooks on the back which lock the shelf in position.



Positioning

Climate Class The chiller is designed to operate safely within a climatic class 5 environment (40°C @ 40% relative humidity). To ensure correct operation and efficient operation, the maximum ambient temperature at the place of installation should not exceed 32°C.

Power Supply The cabinet is supplied with a power cord fitted with a 3-pin plug, which exits behind the refrigeration system. The power cord should be retrieved before the cabinet is positioned. Ensure the power supply can be easily accessed once the cabinet is positioned so the cabinet can be disconnected from the power supply for cleaning and maintenance.

Ventilation Ensure adequate ventilation is provided around the cabinet. The cabinet should not be recessed or enclosed in a cabinet. It is designed for freestanding installation only. The recommended clearance on both sides and at the back of the cabinet is 50mm.

Location When positioning the cabinet:

- Avoid direct sunlight and warm draughts etc.
- Allow adequate space for the door to open fully.
- Ensure the cabinet is positioned on a level surface so the door shuts and seals correctly, and to prevent the condensate tray from overflowing.

Levelling This cabinet has a stabiliser foot located underneath the door hinge. After final positioning, the stabiliser foot should be screwed firmly down to floor level to stabilise the cabinet. Turn the stabiliser foot clockwise to raise the cabinet or anti-clockwise to lower the cabinet.

2 Operation


Cabinet Operation

If the cabinet has been disconnected from the power supply for any reason, allow about 10 minutes before switching it back on. This allows the refrigeration system pressure to equalise before the system is restarted.

Before operating, ensure:

- The cabinet is positioned on a level surface.
- The maximum operating temperature is no greater than 32°C.
- There is adequate ventilation around the refrigeration system.
- There is a gap of at least 50mm around the cabinet.
- The plastic drain pin (included in the bag with the user manual) is placed into the drain hole at the bottom of the cabinet (see image below). This prevents objects from covering the drain hole.
- The cabinet stabiliser foot is screwed firmly down to floor level (see image below).
- The cabinet is allowed to stand for at least 30 minutes before connecting to the power supply.

While the cabinet is operating it is normal to hear gurgling sounds caused by the flow of refrigerant when each cooling cycle ends.



Refrigeration The evaporator fan (located inside the cabinet) should operate continuously **System** from the time the cabinet is plugged in. This may be verified by checking for air movement inside the cabinet. The thermostat will click when the refrigeration system cycles on and off.

Cabinet Light The cabinet interior LED light is controlled by the light switch next to the thermostat knob inside the cabinet. The LED light is non-serviceable and must not be tampered with in any way. If the light is suspected of being faulty, arrange a service call.

Loading The cabinet should be left running for 30 minutes to allow the cabinet to cool down before loading with product. When loading the cabinet shelves with product:

- Allow air space around all the product for even cooling and efficient operation of the cabinet.
- Do not exceed a maximum of 15 kg per shelf.
- Do not allow products to overhang the front or rear of the shelves, as this will affect air flow.
- Do not obstruct air flow from the evaporator fan (inside the cabinet).
- Do not block the drain hole inside the cabinet.

Temperature Adjustment

The storage temperature of the cabinet is regulated by a thermostat located at the back of the cabinet interior. The thermostat temperature setting is preset at the factory and should not require adjustment.


The thermostat knob is graduated from 0 through to 6, with 1 being the warmest and 6 being the coldest. The normal temperature setting is between 2 and 3.

If further adjustment is required:

- To make **colder** turn the thermostat knob **clockwise**.
- To make warmer turn the thermostat knob anti-clockwise.

IMPORTANT

Turning the thermostat knob to '**0**' will switch the refrigeration cooling system off (the cabinet fan and lights will stay on). Do this to defrost the cabinet if an ice buildup occurs.



Door Lock

The chiller is fitted with a security door lock. Use the supplied keys to PUSH and turn the lock.



3 Maintenance

Cleaning

To ensure the chiller continues to run efficiently and reliably, the following routine maintenance should be carried out:

Cleaning Cabinet	Keep the interior and exterior of the cabinet clean by regular wiping with a damp cloth, taking care to keep moisture away from electrical parts. At the same time check the condensation drain hole inside the cabinet, to ensure proper drainage of any condensation. Do not flush the cabinet with water.
	Many commercially available cleaning products contain solvents that may attack the plastic components of this product and cause them to crack. It is important to use only warm water and a small amount of detergent when cleaning this cabinet. Do not use abrasive or corrosive cleaners or boiling water.
	Clean the door gasket once every three months.
	If an ice buildup occurs inside the cabinet, turn the thermostat knob to '0' to switch the cooling system off (the cabinet fan and lights will stay on). Once the cabinet is defrosted turn the thermostat knob back to the normal temperature setting (see page 7).
Cleaning Condenser Coil	The condenser coil is located at the back of the cabinet and should be cleaned at least every three months with a soft brush to remove any dust build-up (see instructions on page 9).
Regular Servicing	A thorough service clean must be completed by qualified service personnel every six months.
Time Frames	Time frames specified above are indicative only. More regular cleaning and servicing may be required depending on cabinet placement and operating environment.

Condenser The condenser coil is located at the back of the cabinet and should be Coil brushed regularly to remove any dust build up. Disconnect the cabinet from the power supply before cleaning the condenser coil. To prevent damage to the coil coating, use a soft brush when cleaning.



Condenser coil

WARNING

Disconnect the cabinet from the mains power supply before attempting any cleaning or maintenance.

Servicing

This refrigerator must only be serviced by SKOPE authorised service agents. Only SKOPE authorised and supplied parts specified for this model may be used.

Cabinet Light The cabinet interior light is non-serviceable and must not be tampered with in any way. If the light is suspected of being faulty, arrange a service call.

SKOPE Industries Limited

ABN: 73 374 418 306 AU: 1800 121 535 NZ: 0800 947 5673 skope@skope.com www.skope.com

HB80-2 (HB80-JAL) SERENE Glass Door Cooler User Manual MAN80030 Rev. 3.0 Nov. 2018

© 2017 SKOPE Industries Limited. All rights reserved. SKOPE Industries Limited reserve the right to alter specifications without notice.

S $e \; r \; e \; n \; e^*$ is a registered trademark of SKOPE Industries Limited.