

## REPAIR

All repair work shall be performed by the manufacturer. All other work or modification performed elsewhere may void the warranty, and releases CMC Rescue, Inc. from all liability and responsibility as the manufacturer.

### SAMPLE INSPECTION AND MAINTENANCE LOG

The sample log suggests records that should be maintained by the purchaser or user of rescue equipment.

Equipment Inspection and Maintenance Log			
Item _____ # _____		Date in Service _____	
Brand/Model _____		Strength _____	
Date	How Used or Maintained	Comments	Name

### CMC Rescue, Inc.

6740 Cortona Drive, Goleta CA 93117

USA

805-562-9120 / 800-235-5741

cmcrestue.com

**ISO 9001:2008 Certified**

©2015 CMC Rescue, Inc. Control No. 201107.00.071613

## USER INFORMATION

CMC Rescue recommends separating the User Information from the equipment and retaining the information in a permanent record. CMC also recommends making a copy of the information to keep with the equipment and that the information should be referred to before and after each use.

### INSPECTION

Inspect the equipment according to your department's policy for inspecting life safety equipment. The equipment should be inspected after each use and at least once a year by an inspector that meets your department's training standard for inspection of life safety equipment. Record the date of the inspection and the results in the equipment log or on a tag that attaches to the equipment. Each user should be trained in equipment inspection and should do a cursory inspection, and check component compatibility before each use.

When inspecting the equipment, check the webbing for cuts, worn or frayed areas, broken fibers, soft or hard spots, discoloration or melted fibers. Check the stitching for pulled threads, abrasion or breaks. Check the hardware for damage, sharp edges or improper operation. If any of the above are noted, or if the equipment has been subjected to shock loads, fall loads or abuse other than normal use, remove the equipment from service and destroy it. If there is any doubt about the serviceability of the equipment, remove it from service and destroy it.

## IMPORTANT INFORMATION - PLEASE READ AND SAVE



# FastLink™ Pick-Off Strap

Made in USA  
of US and foreign components



## ⚠ WARNING

- **SERIOUS INJURY OR DEATH MAY RESULT FROM THE IMPROPER USE OF THIS EQUIPMENT.**
- **THIS EQUIPMENT HAS BEEN DESIGNED AND MANUFACTURED FOR USE BY EXPERIENCED PROFESSIONALS ONLY.**
- **DO NOT ATTEMPT TO USE THIS EQUIPMENT WITHOUT PROPER TRAINING.**
- **USE, INSPECT, AND REPAIR ONLY IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.**

## USE

The FastLink™ Pick-Off Strap can be used in various configurations depending on the best leverage in the direction of pull. In some instances it may be easier to remove slack or make an adjustment by pulling in a downward direction; in other orientations this may be easier done by pulling upward. The Pick-Off Strap should be secured to your descent control device or directly to the main / belay line by Prusik hitches or other rope grabs. Avoid connecting the Pick-Off Strap directly to your harness D-ring.

The gates on the Manual Locking carabiners can be kept in the unlocked position, allowing for a quick attachment. However, the gates should be immediately locked and checked once the connections are secure.

When used in conjunction with the CMC Lifesaver Victim Harness (Part No. 202405), one end of the Pick-Off Strap can be pre-connected to the harness. For easy carry and handling, the Pick-Off Strap and Victim Harness may be kept in the storage bag.

### CARRYING, MAINTENANCE & STORAGE

During use, carrying, and storage keep the strap away from acids, alkalis, exhaust emissions, rust and strong chemicals. Do not expose the strap to flame or high temperatures. Carry the strap where it will be protected as the strap could melt or burn and fail if exposed to flame or high temperatures. If the strap becomes soiled, it can be washed in cold water with a mild detergent. CMC Rescue recommends the use of LifeLine Cleaner. Dry out of direct sunlight. Do not dry in an automatic dryer.