

SAMPLE INSPECTION AND MAINTENANCE LOG

The sample log suggests records that should be maintained by the purchaser or user of rescue equipment.

Equipment Inspection and Maintenance Log			
Item _____ # _____		Date in Service _____	
Brand/Model _____		Strength _____	
Date	How Used or Maintained	Comments	Name

CMC Rescue, Inc.
6740 Cortona Drive, Goleta CA 93117
USA
805-562-9120 / 800-235-5741
cmcrescue.com

ISO 9001:2008 Certified

©2015 CMC Rescue, Inc. Control No. 724131.03.070213

USER INFORMATION

CMC Rescue recommends separating the User Information from the harness and retaining the information in a permanent record. CMC also recommends making a copy of the information to keep with the harness and that the information should be referred to before and after each use.

INSPECTION

Inspect the litter harness according to your department's policy for inspecting life safety equipment. The litter harness should be inspected after each use and at least once a year by an inspector that meets your department's training standard for inspection of life safety equipment. Record the date of the inspection and the results in the equipment log or on a tag that attaches to the litter harness. Each user should be trained in equipment inspection and should do a cursory inspection and check component compatibility before each use.

When inspecting the litter harness, check the webbing for cuts, worn or frayed areas, broken fibers, soft or hard spots, discoloration, or melted fibers. Check the stitching for pulled threads, abrasion, or breaks. Check the hardware for improper operation, and note any damage or sharp edges. If any of the above are noted, or if the litter harness has been subjected to shock loads, fall loads, or abuse, remove the litter harness from service and destroy it. If there is any doubt about the serviceability of the litter harness, remove it from service and destroy it.

USE

1. Connect the webbing loop on each leg of the harness to the litter using a locking carabiner. The two shorter (red)

IMPORTANT INFORMATION - PLEASE READ AND SAVE



Litter Harness

Made in USA
of US and foreign components

Product Label

⚠ WARNING

- **SERIOUS INJURY OR DEATH MAY RESULT FROM THE IMPROPER USE OF THIS EQUIPMENT.**
- **THIS EQUIPMENT HAS BEEN DESIGNED AND MANUFACTURED FOR USE BY EXPERIENCED PROFESSIONALS ONLY.**
- **DO NOT ATTEMPT TO USE THIS EQUIPMENT WITHOUT PROPER TRAINING.**
- **USE, INSPECT, AND REPAIR ONLY IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.**

webbing legs attach towards the head of the litter, while the two longer (blue) webbing loops attach towards the foot of the litter. The carabiner should connect at the small square shaped opening made by the top rails of the litter and its vertical supports. Face the carabiner gate towards the inside of the litter and make sure the gate is locked.

2. To adjust the length of the legs, pull the tail end of the web through the tie-down buckle.
3. After adjusting the individual legs, tie a half hitch around each harness leg with the tail end of web to secure the assembly.
4. The litter harness comes complete with a tender line pre-tied to the Delta Quick Link. The litter tender should be connected to the tender line via ascending system.



Always check that all carabiners, connectors and buckles are securely fastened before tension is applied to the straps. Never expose the straps to sharp edges, fire or any situation that will cause damage to the straps while in use.

MAINTENANCE

If the harness becomes soiled, it can be washed in cold water with a mild detergent. CMC recommends the use of LifeLine Cleaner. Dry out of direct sunlight. Do not dry in an automatic dryer.

REPAIR

All repair work shall be performed by the manufacturer. All other work or modifications may void the warranty, and shall release CMC Rescue, Inc. from all liability and responsibility as the manufacturer.