

## INSTRUCTIONS

The cap is supplied with a tear-off safety collar and a built-in piercing pin.

To open:

1. Tear off the safety collar.
2. Push down the cap until the pin pierces the nozzle.

- Ensure that the bonding surfaces are:
  - a) A good fit (Superglue cannot fill bond gaps).
  - b) Non-absorbent. (Will not work on absorbent surfaces such as clay pots.)
- USE ONLY ONE DROP per square cm.
- Do not spread the drop, let this occur naturally when the two surfaces are brought together. (Good results can sometimes be obtained by placing the dry surfaces together and then applying the adhesive to the joint line so that it "wicks" in.)
- A handling bond will develop within seconds. However, for best results wait about  $\pm 20$  minutes before using.
- Wipe the tip with a dry tissue before closing.

### TIME TO SET

- A handling bond in  $\pm 30$  seconds.
- Full strength  $\pm 20$  minutes.
- Setting time is very dependant upon the materials being bonded and atmospheric humidity. (Low humidity will slow down the setting time.)

### NOT RECOMMENDED FOR

- Porous or absorbent surfaces.
- Large bond gap repairs.
- Polyethylene, PTFE, polypropylene and perspex.

### WARNING

Take care in handling. This glue bonds skin in seconds. Should this occur, flush with water and do not force apart. Get immediate medical attention for eye, mouth or internal contact.

**Refrigerate for best shelf life.**

**Limited shelf life.**

**KEEP AWAY FROM CHILDREN.**

# Super glue

#### POLICY STATEMENT

"The performance  
of our products  
must exceed all others  
on the  
World Market"

*KGM Pratlley*  
CEO

PRATLEY (PTY) LTD (1996/003890/07)  
P.O. BOX 3055 • KENMARE 1745  
SOUTH AFRICA

[www.pratlley.com](http://www.pratlley.com)

## AANWYSINGS

Die proppe word verskaf met 'n afskeurbare veiligheidsring en 'n ingeboude speld.

Om oop te maak:

1. Skeur die veiligheidsring af.
2. Druk die proppe af totdat die speld die tuit deurboor.

- Sorg dat die oppervlakte wat verbind moet word:
  - a) Goed by mekaar pas. ("Superglue" kan nie verbindingsgaping opvul nie.)
  - b) Nie-absorberend. (Sal nie op absorberende oppervlakte soos kleipotte werk nie.)
- GEBRUIK NET EEN DRUPPEL per vierkante cm.
- Moenie die druppel versprei nie, laat dit natuurlik gebeur wanneer die twee oppervlakte saamgevoeg word. (Goeie resultate word soms verkry deur die droë oppervlakte saam te voeg en dan die kleefmiddel op die voeglyn aan te wend sodat dit invloei.)
- 'n Hanteerbare verbinding sal binne sekondes ontwikkel. Vir die beste resultate, wag vir ongeveer  $\pm 20$  minute voor gebruik.
- Vee die puntjie met 'n droë sneesdoekie af voordat dit toegemaak word.

### TYD OM TE BIND

- 'n Hanteerbare verbinding  $\pm 30$  sekondes.
- Volle sterkte  $\pm 20$  minute.
- Settyd hang baie af van die materiaal wat verbind word en atmosferiese humiditeit. (Lae humiditeit sal die bindtyd verleng.)

### NIE AANBEVEEL VIR

- Poreuse of absorberende oppervlakte.
- Herstelwerk met groot verbindingsgapinge.
- Poliëteleen, PTFE, polipropileen en perspex.

### WAARSKUWING

Hanteer versigtig. Hierdie kleefstof bind met die vel binne sekondes. As dit sou gebeur, spoel af met water en moet nie probeer van mekaar af forseer nie. Kry onmiddellike mediese behandeling vir oog, mond of inwendige kontak.

**Bêre in yskas vir goeie raklewe.**

**Beperkte raklewe.**

**HOU WEG VAN KINDERS.**

10/3/2015