

User Manual and Operating Instructions


It is our privilege to have you as one of the very first Enflux developers. As you begin using the system please know our company is focused on providing you with the best experience possible. Feel free to contact any member of the Enflux team for assistance at any time. We look forward to working with you and are proud to provide you *The Motion Capture Suit for Everyone!*

1. Contents

Inside your DevKit, you will find the following items:

- (a) Enflux shirt
- (b) Enflux pants
- (c) Wall adapter
- (d) Bluetooth dongle
- (e) 2 x Micro USB cable

(a) Enflux shirt



(b) Enflux pants

(c) Wall adapter



(d) Bluetooth dongle



(e) 2 x Micro USB cable



2. Charging Your Shirt and Pants

Prior to the first use, we advise fully charging your shirt and pants for **90 minutes**. (i) Plug the wall adapter into an outlet. (ii) plug the 2 micro USB cables into the wall adapter, and (iii) plug the micro USB cables into the USB ports in the chest and waist modules (pictured below). Please note the charging port is located on the inside of each garment piece.



3. Operating the system

Turn ON the system by FIRMLY pressing the front of the chest and waist modules. The units immediately become discoverable as advertising BLE devices.

You are then free to connect to an Enflux SDK or any Enflux-enabled application!

After completing your session and the Bluetooth connection has been terminated, the device will return to advertising mode. If a connection is not established within 30 seconds, the device will reenter a power-saving sleep. The system supports up to 10 hours of continuous use.

4. Care and washing

For best results, please hand wash with cold water and hang dry.

PLEASE DO NOT MACHINE WASH OR MACHINE DRY YOUR ENFLUX DEVKIT.

Contact Us

Technical Support

doug@enfluxmobile.com

elijah@enfluxmobile.com

Sales

mickey@enfluxmobile.com