



**ROOK SERIES
OPERATING INSTRUCTIONS**

- 920-310 Rook CheckMate
- 940-010 Rook MD1, White
- 940-302-470 Rook Blue 470nm
- 940-310 Rook MD3, White + UV
- 940-311 Rook UV 380 + 395nm
- 940-312 Rook Blue 450 + 470nm
- 940-365 Rook UV 365nm
- 940-R2A Rook R2A Forensic FLS Kit
- 940-R3A Rook R3A Forensic FLS Kit
- 940-R3B Rook R3B Forensic FLS Kit



Please read the below before using your Rook flashlight as it relays beneficial operating and safety information.

PHYSICAL CHARACTERISTICS ACCORDING TO P/N:

Model	Dimensions
920-310	5.8" x 1.1" x 1.5" (147mm x 28mm x 38mm)
940-010	4.9" x 1.0" x 1.3" (125mm x 25mm x 33mm)
940-302-470	5.1" x 1.0" x 1.3" (129mm x 25mm x 33mm)
940-310	4.9" x 1.0" x 1.3" (125mm x 25mm x 33mm)
940-311	
940-312	
940-365	

LED & EXTERIOR COLOR ACCORDING TO P/N:

Model	LED Color	Exterior Color
920-310	1 White LED	Black
940-010	1 White LED	
940-302-470	5 470nm	
940-310	1 White/4 UV LEDs	
940-311	1 UV 380nm / 4 UV 395nm	
940-312	1 Blue 450nm / 4 Blue 470nm	
940-365	1 UV 365nm	

BATTERIES: TYPE & BATTERY LIFE

Model	Battery Type	Full Power*
920-310	Two (2) CR123 or One (1) 18650	Runtime of 18650 battery: 100 min. High Power 200 min. Low Power
940-010		3-4 hrs
940-302-470		
940-310		
940-311		
940-312		
940-365		5 hrs

*Battery life may vary according to Mode Selected, Battery Quality, and prevailing Ambient Conditions.

NOTE:

- Mixing of used and new, or different brand batteries is not recommended as this could lead to leakage or explosion.

BATTERY INSTALLATION/REPLACEMENT

All Rook Series Flashlights follow the below:

1. Each flashlight consists of: Head, Handle and End Cap.
2. To install batteries, first remove the End Cap at the rear of the Main Body.

3. Insert required batteries with the positive terminal (a plus sign) facing the front of the flashlight.
4. After inserting all batteries, replace the End Cap securely.
5. Test the light's performance by activating the On-Off Switch, located at the End Cap.



OPERATIONAL MODES ACCORDING TO P/N:

For P/N 920-310, 940-010:

Mode	
1	HIGH
2	LOW
3	Turbo-Strobe

For P/N 940-302-470:

Mode	
1	On
2	Off

For P/N 940-310:

Mode	
1	White Light
2	UV Light
3	Turbo-Strobe (white light only)

For P/N 940-311 & 940-312:

Mode	940-311	940-312
1	All On	All On
2	UV (380nm)	Blue (450nm)
3	UV (395nm)	Blue (470nm)

For P/N 940-365:

Mode	
1	LOW
2	HIGH

ROOK KITS:

The Rook Forensic Kits include a Custom Case, Goggles (Orange and Yellow), as well as the following part numbers:

- R2A Kit: 940-311, 940-312
- R3A Kit: 940-010, 940-311, 940-312
- R3B Kit: 940-010, 940-365, 940-302-470


PRODUCT DURABILITY, ENVIRONMENTAL CONSTRAINTS & CERTIFICATIONS:

- Meets NFPA 1971-2007 Fire Resistant Requirements: 500°F/ 260°C for 30 minutes

P/N 920-310 & 940-010 ONLY:



P/N 940-310 ONLY:



CARE/CLEANING:

Your FoxFury is a professional tool, but regular maintenance and care will maximize performance for you. As needed, wash your FoxFury using a soft washcloth, clean water and a mild soap. Be sure that the battery pack is SEALED before washing. When done, pat dry with a damp cloth.

WARNINGS:

IMPORTANT

FoxFury, LLC is not responsible for the incorrect use of any FoxFury Lighting product.

- Lights are strong enough to cause damage to the human eye.
- Do not stare into LEDs for long periods of time or from a close range (less than 2 feet).
- FoxFury, LLC is not responsible for any injury or damage caused during the use of this product.
- Usage of this product must be supervised by an adult when it is being used by a minor.
- Any FoxFury product should be operated at speeds safe enough to maneuver around surrounding obstacles.
- Do not use under the influence of drugs or alcohol.

CAUTION: Light Head can get Hot with prolonged use.

STROBE

FoxFury's Turbo Strobe is purposely designed to induce disorientation. Prolonged viewing may produce vertigo or even vomiting. Note that the frequencies implemented are well below the ones reported to cause photo-induced seizures. As with all products, use common sense while operating.

UV LIGHT

**Avoid direct eye exposure to UV light.
Keep out of reach of children.**

- The UV LED during operation radiates intense UV light.
- Do not look directly into the UV light during operation, even for a brief period. This can be harmful to the eyes due to the intensity of the UV light.
- When viewing with the UV light, please use UV filtered glasses to avoid damage by the UV light.

LIMITED WARRANTY

FoxFury Limited Warranty & Customer Care Information

FoxFury, LLC ("FoxFury") warrants to the purchaser of this product ("Buyer") that for a period of two years following purchase, this product will be free from defects in material and workmanship and will function in substantial compliance with FoxFury's written specifications for this product as specified in the instruction manual or on FoxFury's

website located at www.foxfury.com. Buyer's exclusive remedy shall, in any case, be limited, at FoxFury's election, to: A) repair or replacement of the defective product; or B) refund of the purchase price for this product. THE FOREGOING WARRANTY IS THE ONLY WARRANTY MADE BY FOXFURY WITH RESPECT TO THIS PRODUCT. TO THE EXTENT ALLOWED BY APPLICABLE LAW, THERE ARE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND BY THE FOXFURY, EXPRESS OR IMPLIED, WITH RESPECT TO THE CONDITION OR PERFORMANCE OF THIS PRODUCT, INCLUDING, BUT NOT LIMITED TO, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. **This limited warranty shall not apply if this product is not stored, handled, installed or used in strict accordance with manufacturer's specifications and instruction manuals, or which has been subject to misuse, alteration, negligence or accident.**

1. The damaged part or product must be returned to FoxFury **PRIOR TO** any repair or replacement. Shipping costs are the responsibility of the claimant.
2. You must obtain a return authorization (RMA) number from FoxFury prior to returning products. FoxFury is not responsible for any damage incurred while in transit.
3. Buyer will be required to show proof of purchase – No Exceptions.
4. Any modifications to light, cable or battery pack automatically voids all warranties on this product.

All warranty inquiries should be directed to FoxFury's Customer Service Department to handle all warranty/repair related inquiries.

TO THE EXTENT ALLOWED BY APPLICABLE LAW: (A) IN NO EVENT, WHETHER DUE TO BREACH OF WARRANTY HEREUNDER OR ANY OTHER CAUSE WHATSOEVER, SHALL FOXFURY BE LIABLE FOR OR OBLIGATED IN ANY MANNER TO PAY CONSEQUENTIAL, INCIDENTAL OR INDIRECT DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, COST OF SUBSTITUTE PRODUCTS AND PERSONAL INJURY OR PROPERTY DAMAGE, WHETHER SUCH CLAIM IS BASED ON CONTRACT OR TORT OR ANY OTHER THEORY OF LAW, AND (B) FOXFURY'S ONLY DUTIES IN CONNECTION WITH THE SALE OF THIS PRODUCT SHALL BE TO HONOR THE LIMITED WARRANTY SET FORTH HEREIN. TO THE EXTENT THAT THIS LIMITED WARRANTY IS INCONSISTENT WITH APPLICABLE LAW, THIS STATEMENT SHALL BE DEEMED MODIFIED TO BE CONSISTENT WITH SUCH APPLICABLE LAW.



FoxFury, LLC
 Oceanside, CA 92056 USA
 Toll-Free: 844-FOXFURY
 Tel: 760.945.4231
 Fax: 760.758.6283
 Email: custserv@foxfury.com
www.FoxFury.com

All FoxFury products are designed in Oceanside, CA. All FoxFury products are manufactured with the highest quality USA and foreign parts. Products are assembled in either FoxFury's controlled plant in Asia or the USA, under strict quality control.