

## EL Series - Mach 3

### MLM990H Quick Reference Guide



#### Initial Start-up

When your spa is first actuated, it will go into Priming mode. *Please see the M-7 Installation Instruction Manual for complete instructions on Power-up and Pump Priming.*

The Priming mode will last for up to 4 minutes and then the spa will begin to heat and maintain the water temperature in Standard mode. Follow the on screen instructions. Make your choice, then press Select (○). If left alone, the system will resume after 4 minutes. The Home display screen will then appear after completion.

#### To Navigate

The front panel ring designates Up ↑, Down ↓, Left ←, Right →. ○ chooses menu selection.

#### Setting the Time

"Home" > Set > ○ > Time of Day > ○.  
Arrow ↑ or ↓ to select "Time of Day". Then ○.  
Arrow ↑ or ↓ to change hour.  
Arrow → to select minutes. Press ↑ or ↓ to change.  
Repeat to change AM/PM. To Save and Exit: ○.

#### Setting the Spa Temperature Using Fast Keys


From Home display screen, highlight "Fast Keys". Press ↑.  
Set the spa temperature with ← or →, then ↓ to Home.

#### Fast Keys Give Quick Access to System Set-up

Fast Keys quickly shows status and allows control of a device. (See User's Manual: "Fast Keys--Programming".)

From the Home display screen, select "Fast Keys", then ○. The circle represents the four directional keys.

Pressing the designated arrow key will turn the function to Hi/Med/Low or On/Off. Press ○ to exit.



## Set Menu Presets Your Equipment

The Set menu allows you to program your system, and view diagnostic & software information. Move within each menu with the arrow keys. Follow on screen instructions.

⊙ to activate any menu or device. ← to Exit. Options depend on devices installed.

---

### To Program

Filter Cycles: “Home” > Set > ⊙ > Filter Cycle > ⊙.

Fast Keys: “Home” > Set > ⊙ > Fast Keys > ⊙.

Mode, Change Heat: “Home” > Set > ⊙ > Mode > ⊙.

User Settings: “Home” > Set > ⊙ > User Settings > ⊙.

Panel Settings: “Home” > Set > ⊙ > Panel Settings > ⊙.

Diagnostics: “Home” > Set > ⊙ > Diagnostics > ⊙.

Link Device: “Home” > Set > ⊙ > Link Panel > ⊙.

Network / Link another Panel to Control System:

“Home” > Set > ⊙ > Network > ⊙.

**To View** Version Info.: “Home” > Set > ⊙ > Diagnostics  
> ⊙ > Versions > ⊙.

## Spa Button Menus Turn Accessories On or Off

“Home” > Spa > ⊙ > Spa Functions menu.

The “Spa Functions” menu allows you to access: Jet Control, Lighting, Blower, Mister, Options, Chemistry, Standby Mode, and Stir.

Select and highlight a device, press ⊙, then move within the Spa Functions/device menu with the arrow keys.

Press ⊙ to turn the accessory On/Off, or High/Med/Low. Left Arrow (←) to exit. *(Note: Devices must be set up for the Spa buttons to function. See User Guide for set up.)*

---

### About Heat Mode

“Home” > Set > ⊙ > Mode > ⊙.

You can choose from Standard, Economy, or Sleep modes when using the heater. Select the mode, then ⊙.

*Standard* mode maintains the desired temperature.

*Economy* mode heats the spa to set temperature only during filter cycles.

*Sleep* mode heats the spa to within 20°F (11°C) of the set temperature only during filter cycles.

Arrow Left ← to return to “Spa Settings”.

***Refer to User Guide for additional information***