









KEY FEATURES

- FLEX TEMP
- ONYX ATOMIZER
- SAFE SESH HEAT CYCLE
- PASS THROUGH CHARGING
- SESH MODE
- MANUAL MODE

HOW TO USE YOUR ELECTRO BARREL

6 GET STARTED

Press the button 5x to turn on & off.

Lift the lid and load your extract into the Onyx Atomizer. Close the lid.

Grip the bottom of the water chamber and pull to remove it. Fill halfway with water and replace.

SETTING UP YOUR ELECTRO BARREL

Press the button 3x to switch between the 3 voltage levels. Each level has a different LED color and heats to a different temperature range:

GREEN 2.7V 400-500°F BLUE 3.2V 500-600°F RED 3.7V 600-700°F

The Electro Barrel will remember the voltage level you selected during your previous session. It will remain at this level unless you click the button 3x.

? HOW TO USE

There are 2 ways to operate the Electro Barrel:

Manual Mode: Press the button to heat the device while you inhale, and release when you exhale.

Sesh Mode: Click the button twice to activate a Safe Sesh Cycle. The device will heat & LED will flash without you holding the button, and shut off once the cycle is complete.

PRO TIP: Use a finger as a carb cap to cover the carb hole in the lid to control the airflow.

SAFE SESH CYCLES

The Safe Sesh Cycle for all 3 voltage levels runs for 15 seconds.







CONNECTION ISSUE OR ERROR CODE

3 White LED Flashes: Short circuit in device or atomizer.

5 White LED Flashes: Open circuit in device or atomizer.

CHARGING

Needs to Charge: 5 red LED flashes.

While Charging: Flashing white LED.

Charge Complete: Solid white LED.

The Electro Barrel takes 120 minutes to fully charge.

SAFE GUARDS IMPORTANT! SAVE THESE INSTRUCTIONS!

- ▲ Keep away from water.
- ▲ Only charge indoors.
- △ Only charge with included charger no others!
- Only use in legal and adult use state/providence/country.
- △ Only use approved Ooze attachments.
- A Never leave unattended around children/pets.

- A Never disassemble.
- △ Only use wall outlet for charging.
- △ Do not leave unattended while charging.
- △ Do not leave charging overnight.
- Always dry thoroughly after cleaning.