

our mini guide for...

Destainer and Renovator

DELPHIS*

*eco PROFESSIONAL CLEANING

Application and Directions

Machine destaining: Wash and rinse glasses and tea and coffee cups on a normal cleaning cycle. Replace machine detergent with Destainer and Renovator and run machine again.

Manual destaining: Dilute 1:25 parts water. Put glasses and tea and coffee cups into a sink or bowl of warm water, soak for 10-15 minutes. Increase contact time for heavy soiling. Repeat if necessary.

Sterilisation: Make a 1% solution in clean water with a contact time of more than 2 minutes.

In place sanitation: Rinse pipes/clusters with clean water to remove dirt and solids. Make up a solution of 0.5% in hot water. Set to waste until temperature reaches 50°C on discharge and return. Recirculate for 15 minutes. Rinse with water after cleaning operation. Soak all ancillary equipment in a 1% solution. Treat recirculating systems with 1-2% dilution in water for 2 hours.

Proper dosage saves cost and minimises environmental impact: Delphis Eco encourage proper dosage and users to reduce waste going to land fill by recycling empty bottles.

Main Use



COSHH



Health and Safety

Use only as directed. Do not mix different cleaners. Seek medical attention if in discomfort or if any symptoms persist.

Eye Contact: Avoid contact with eyes, if product gets into eyes, rinse with water.

Skin Contact: Avoid contact with skin, if product gets onto skin wash with water and remove any contaminated clothing.

Ingestion: Do not drink, if swallowed drinking water may be beneficial, do not induce vomiting.

Inhalation: Avoid inhaling product, move to fresh air if in discomfort.

don't forget PPE.. 

Always wear the correct protective clothing if required. For best results we recommend using the correct dosing and colour coded microfibre cloths - please ask your manager for details.

how to dispose...

Dirty, used washing solution should be disposed of via drains that lead only to foul sewers. Do not allow detergent solutions to contaminate surface water drains. In the event that concentrated product should need to be disposed of, run small amounts to foul waste, diluting with plenty of water. For larger quantities, seek advice on disposal from the local authorities. Delphis Eco products are packed in fully recyclable containers. Empty containers should be rinsed thoroughly, the washings being run to foul waste. The containers may then be sent for recycling. Dispose of all waste in a responsible manner. Be aware of the environment.

