



## **AIRBRUSH INSTRUCTIONS**

### **Set Up The Airbrush for Stain Use:**

Begin by running water through the Airbrush for approximately 15 seconds.

Adjust the dial to allow a 2-3 mm opening, which controls the Stain's airflow.

Perform a test spray on a cotton round to check for even dispensing. Test across all pressure modes. We recommend using your machine on the lowest setting.

Once you achieve an even spray, the Airbrush is ready for use.

### **Brow Preparation:**

Complete a patch test before proceeding with the service.

Cleanse the brow area with an oil-free foaming cleanser. Rinse with a damp cotton pad. Ensure brows are dry and free of oils and sebum for optimal Stain Hybrid Dye adhesion.

Brush the brows and map as desired.

### **How to Apply Brow Borders:**

Use mapping thread or paste to shape the brows as desired.

Starting from the head of the brow, apply the bottom Brow Border at a slight upward angle towards the arch, following the natural brow shape.

Continue applying the border from the arch to the tail at a slight downward angle.

Ensure the Brow Borders are aligned neatly and press down firmly with fingers or the back of tweezers. Inadequate application may allow Stain to seep through.

Repeat the same process for the top Brow Border, ensuring symmetry and secure placement.

## Airbrush Stain Application Process:

Ensure the borders are secure to prevent the Stain Hybrid Dye from seeping beyond the desired area.

Visually inspect the 'Brow Borders' on both eyebrows to ensure symmetry.

Shake the Stain Hybrid Dye bottle well before use. Fill the dispenser with a 1:1 ratio of Stain with Liquid Oxidant 3%, or approximately 8 drops Stain to 8 drops Liquid Oxidant, adjusting based on the size of your dispenser.

Set the Airbrush Machine to your preferred speed and test spray onto a clean dry cotton pad to check shade and consistency of the spray.

Spray a light layer of Stain from the tail of the eyebrow towards the front of the brows. Let this layer set for 1-2 minutes. You may choose to work on each brow individually or simultaneously.

Apply a second layer of Stain, following the same direction – from tail to front. Allow this layer to set for 1-2 minutes before proceeding.

For the final layer, work from the tail towards the front, ensuring thorough coverage for the client's desired look. The number of layers will determine the saturation level for the desired outcome.

Typically, 2-3 layers are recommended for most clients. For a more natural appearance, 1-2 layers is recommended.

After completing the Stain layering, carefully remove the Brow Borders. If required, use Brow Code Tint Remover or a damp cotton tip to clean the edges of the Airbrush brows.

Allow the Stain to remain on the brows for 8 to 12 minutes, depending on the desired intensity and saturation level.

Gently remove the Stain with a damp cotton pad, starting from the head of the brow and moving towards the tail. Be careful not to scrub back and forth to avoid removing the Stain Hybrid Dye from the skin.

Brush the eyebrows into place to complete the Airbrush Stain application process.

## Ombre Airbrush Application Technique:

Apply each layer of Stain from the tail towards the middle front of the brow.

Once the desired layers are applied, using a gentle speed apply the Stain at an upward angle, softly moving from the front to the mid-front of the brow, ensuring a soft shading effect.

Allow this to set for a few seconds before removing the Brow Border.

If the ombre effect seems too dark, lightly use a cotton tip to blend and soften the Stain as needed.

Allow the Stain to remain on the brows for 8 to 12 minutes, depending on the desired intensity and saturation level. Gently remove the front of the brows by stamping a damp cotton round into the brow and swiping upwards softly. Blend the front of the brow with a clean brush to soften the Stain line between the front and the body of the brow and continue processing for desired time.

Gently remove the Stain with a damp cotton pad, starting from the head of the brow and moving towards the tail. Be careful not to scrub back and forth to avoid removing the Stain Hybrid Dye from the skin.

Brush the eyebrows into place to complete the Airbrush Stain application process.