

# DECYPHERING THE CHEMEX

## YOU WILL NEED

CHEMEX

CHEMEX  
FILTER

SCALE

TIMER

KETTLE

## STEPS

Grind 20g of coffee into a medium fine grind.

Place folded filter with triple layer covering spout.

Pour Water (90 to 94°) over the filter to wash out the papery taste and to preheat the Chemex chamber.

Swirl around and then discard the water.

Pour ground coffee into filter and and tap to level the coffee for even saturation.

Pour 40ml of water (90 to 94°) to wet all the coffee grounds.

Rest for 30 seconds. This is called the "Blooming Process" which allows for degassing of the coffee grounds.

Pour 80ml of water (90 to 94°) over a period of 30 seconds. Rest for 30 Seconds

Next, pour 100ml of water (90 to 94°) over a period of 30 seconds.

Discard filter and swirl coffee around.

Pour a cup, sit back, and liberate yourself.

