

DECYPHERING THE V60

YOU WILL NEED

CHEMEX

CHEMEX
FILTER

SCALE

TIMER

KETTLE

STEPS

Grind 20 Grams of coffee into a medium fine grind.

Place V60 filter on V60.

Pour water (90 to 94 °) over the filter to wash out papery taste and to preheat V60 and Vessel.

Swirl around and then discard the water.

Pour ground coffee into V60 and tap to level the coffee for even saturation.

Pour 40 ML of water (90 to 94 °) to wet all the coffee grounds.

Rest for 30 seconds. This is called the "Blooming Process" which allows for degassing of the coffee grounds.

Pour 80ml of water over a period of 1 Minute, and then rest for 30 seconds.

Pour 100ml of water over a period of 2 Minutes, and then rest till the coffee is no longer dripping down.

Discard V60 filter. Swirl Vessel.

Pour a cup, sit back, and liberate yourself.

