







Quick Reference Guide - Tiiwee Home Alarm System - Door&Window sensor

Connect a tiiwee door & window sensor to the A1 or A2 Siren in 4 easy steps:

A2 Motion Detector Siren	A1 Siren (Home Alarm Starter Kit)	STEPS
		<p>1.</p> <p>Enter the pairing mode by pressing the SET button for <u>5 seconds</u>.</p> <p>A1 Siren: All 4 LED's are now on</p> <p>A2 Siren: The detection window is lit continuously. This means that the A2 is in ready to be connected to a door sensor.</p>
		<p>2.</p> <p>A1 Siren only: <u>Short press</u> the SET button to select a zone. The top LED is now on. Short press again to select other zones.</p>
		<p>3.</p> <p>Activate the door sensor(s) by moving the magnet away from the sensor. The light on the sensor lights up. The A1 and A2 confirm correct connection by 2 beeps.</p>
		<p>4.</p> <p>Press the On/Off Button on the Alarm unit to exit the pairing mode</p>

IMPORTANT:

Please also refer to the user manual of the Tiiwee Home Alarm Kit or the A2 Motion Sensor Alarm. Only use original tiiwee products to ensure compatibility.

For questions and answers, please visit us at www.tiiwee.com, our YouTube channel. We can also be reached by Email at info@tiiwee.com.