


EYELET TAPE SEWING INSTRUCTIONS




Eyelet Tape is suitable for light to medium weight fabric.

TAPE MEASURING GUIDE

The inhome Eyelet Tape has plastic spacers fixed to the back of the tape that give two pleating positions. The outer clips produces a wider fold with 2 1/4 times fabric fullness whilst the inner clip offers a slightly narrower pleat with a fullness of 2.

When purchasing the tape please allow one extra ring to ensure the correct starting position of the tape. The first eyelet for the leading edge of the curtain is cut between the two plastic pleating tabs. The outer edge should match the leading edge. There should be an even number of rings across the tape.


STAGE 1 & 2



Simply sew the tape onto the back of the fabric ensuring the plastic clips are visible. If lining your curtain, only take the lining to the bottom row of stitching on the tape.


Carefully cut away the fabric from inside the eyelets. Do not worry about fraying; the Eyelet Rings will hide any untidy edges.

STAGE 3



Clip on your chosen Eyelet Ring

STAGE 4



Hook the plastic spacers together to achieve desired fullness

Care instructions: Wash by hand or Dry Clean. Before cleaning, gently remove the inhome Eyelets from the curtain. DO NOT force the eyelets out by hand as this may cause the tape to come away from the metal rings. Carefully ease the eyelets away with a screwdriver or similar implement that will give gentle leverage.