

Motion Detection Feature on HD2

The “motion detection” feature on your HD2 allows video recording to start and stop automatically when motion up to 10-15 feet away is detected in the camera’s field of view.

The use of this feature you described below is one way it can be utilized.

Another way is for recording animals in the wild.

When there is continuous motion in the field of view, the camera will keep on recording video. But if there is no more motion detected, the camera will stop recording after 5 seconds.

If the user wants to keep the camera on for an extended period of time, an external battery power source fed through the USB port must be used since the internal li-ion battery will last for about 2.5 to 3 hours on a full charge. The external battery power source must provide the standard USB 5 volts DC and 1 amp.