


## S.A.M.<sup>2</sup> 1000

## 10" SIDE EXTENSIONS ITEM 16901



4. Wheel stops and ramp extensions are mounted as shown using the slots found at the ends of the extensions panels.

## Stabilization bar directions

Unscrew cap from one of the ends of the stabilization pipe. Insert bolt thru the drilled hoe in the pipe. Secure bolt to the pipe by installing and tightening nut. Slide the pipe thru the square tube at the lower end of the lift frame. Install the other bolt and nut to the pipe. Keep the pipe centered on the lift frame. Install the pipe cap and tighten. Check to make sure that both bolts and pipe caps are tightened securely.

THE CARLSON COMPANY
Your Source For Professional Service Equipment