

TORP MOTOR TM25.

The TM25 motor has been developed for the SurRon Light Bee and the Torp Controllers, with the possibility of being paired with other controller brands. If used with other controller brands, contact those controller manufacturers if you need help with setting it up.

How to use it with Torp Controllers:

- Once the motor is installed on the bike and connected to the Torp Controller (TC500 or TC1000), connect to the Torp App
- Visit the 5th screen of the Torp App and navigate to the CALIBRATION
- Start the SETUP WIZARD and select the TM25 from the options presented
- Follow the calibration wizard so everything is set up correctly

IMPORTANT:

-The nut is counter-clockwise (as opposed to Stock SurRon motor, where the nut is clock-wise). Take this into account during installation.

