

barneys  
professional

# PROFESSIONAL DIGITAL WAX HEATER

INSTRUCTION MANUAL | MODEL: B1200



DESIGNED FOR THE WAX PROFESSIONAL OR PERSONAL USE  
CONVENIENT SMART HEATING WITH LED TOUCH CONTROL

# BARNEYS PROFESSIONAL DIGITAL WAX HEATER




Barneys Professional Digital Wax Heater has been designed for traditional hot wax treatments. It's modern and sleek design features all the must haves to help create the perfect waxing experience and streamline efficiencies in the treatment room. Its Teflon™ non-stick pot makes it a breeze to clean!

## FEATURES INCLUDE:

- Digital temperature LED display panel
- Strong material for long-lasting durability
- Easy to clean non-stick Teflon™ pot
- Perfect for both Hot wax and Strip Wax
- 500ml wax heating capacity
- Effortlessly heat wax with fast heating time
- Smart temperature memory
- See-through lid cover
- High heating temperature 165°C (329°F)



## INSTRUCTIONS FOR USE:

- 1: Remove lid and place wax inside the nonstick pot
2. Plug the lead into your power supply and touch the 'Power On'  symbol to turn machine on
3. To set desired temperature, press  to increase the temperature and/or  to reduce the temperature
4. The wax heater will begin to warm the wax automatically.
5. You can set the LED temperature display by selecting the °C/°F symbol

## WAX HEATING RECOMMENDATIONS:

Suggested temperature to melt Hard and Strip Wax is at a maximum of 120 °C.  
Suggested temperature to melt Hard Wax and Strip Wax in a silicone or removable pot is 165°C.

Always test temperature of wax before applying to skin.

SUITABLE FOR HARD & SOFT WAX



### CLEANING INSTRUCTIONS:

1. Disconnect heater from its direct power supply
2. Using a soft cloth and a non evasive cleaner, gently wipe away wax. It is recommended Barneys Wax Remover Citrus Cleaner is used to cleans away excess wax in and/or on the wax heater. In order to help keep your wax heater in optimal condition, be sure to follow up with a gentle wipe using a clean soapy cloth

### **DO NOT:**

1. Use other solvents to clean the wax heater or you may damage the non-stick coating
2. Use sharp instruments to clean or scrape wax residue
3. Immerse wax heater under water or soak wax heater parts
4. Clean heater with excess solutions or water

## CAUTIONS:

1. Never immerse your wax heater in water
2. Always unplug device when setting down and whilst cleaning
3. Ensure the device is kept on a stable surface when in use
4. Check the voltage of your power source is compatible with the wax heater before use
5. Always keep out of reach of children and pets
6. Never use next to a water source, bath tubs or sinks
7. Keep the wax heater out of direct sunlight and ultraviolet radiation
8. Remember to unplug the wax heater before removing wax pots or tins

## PRODUCT INFORMATION:

Model: B1200

Capacity: 500ml

Maximum Heating Temperature: 165°C (329°F)

Power: 100W

Voltage: 110V-220V ~

Frequency: 50-60Hz

Size: Size: 154 x 183 x 111mm

Warm Mode: PTC Warming

## WARRANTY CONDITIONS | MODEL: B1200

### BARNEYS PROFESSIONAL WAX HEATER

#### 1 YEAR MANUFACTURERS WARRANTY FROM DATE OF PURCHASE

Thank you for choosing to use our wax heater. In order to maintain your warranty, please ensure you follow the safety and cleaning instructions.

Please note, the warranty is void if :

- The wax heater has been damaged due to incorrect use or handling.
- The wax heater has been dismantled
- The wax heater has been used with incorrect power and voltage as noted
- A receipt or proof of purchase cannot be supplied

MODEL: \_\_\_\_\_ DATE OF PURCHASE: \_\_\_\_\_

SUPPLIER NAME: \_\_\_\_\_

SUPPLIER ADDRESS: \_\_\_\_\_

Note: Please retain this document along with receipt for warranty purposes.