

Setup

(1) The OH 75 features:

- 2x Male junior/ female baby Pin Posts (**Fig .A**)
- 2x Track Clamps (**Fig . A**)
- 1 x Camera Mounting Plate (**Fig. B**)

NOTE: - Each Pin Posts comes already screwed into the clamp but can be easily unscrewed for alternative mounting options

- Track Clamps can accommodate rails with a diameter between 1" and 2"

(2) Mount one of the Pin Post/Track Clamps to a light stand as in **Fig. C**.

Alternatively, unscrew the Pin Post from the Track Clamp and mount the Track Clamp directly onto any tripod with a 1/4-20 male mounting option.

(3) Slide the rail in between the Track Clamp as pictured in **Fig. C**.

(4) Mount the Camera Mounting Plate by sliding the rail in between the 2 clamps on the Camera Mounting Plate as in picture in **Fig. D**.

(5) Attach the other end of the rail to the second Track Clamp.

(6) Mount the camera onto the Camera Mounting Plate. The setup should look like in **Fig. E**




Fig. A




Fig. B




Fig. C




Fig. D




Fig. E