


RAISED AIR MATTRESS With Built-in 120V AC Pump


This product may be covered under one or more of the following U.S. and / or foreign patents: U.S. Pat. Nos.: 2,425,162; 2,610,119; 5,827,052; 6,004,116; 6,120,264; 6,332,760 B1; 6,457,192; 6,581,223; 6,679,686 B2; 6,722,306 B1; 6,754,925 B1; 6,754,926 B2; 6,763,540; 6,793,469; 6,990,700 B2; 7,020,921B2; 7,040,347 B2; 7,114,207; 7,120,955; 7,152,265; 7,246,394; 7,306,694; 7,313,837; 7,334,274; 7,346,950 B2; 7,365,277; 7,387,920; 7,475,443; 7,497,416 B2; 7,597,123; 7,647,662; 7,739,760; 7,703,160; 7,739,763; 7,922,461B2; 8,024,830 B2; 8,051,517; 8,151,390; 8,214,953; 8,549,686; 8,801,392; 8,863,771; 9,062,668 B2; 9,121,519 B2; 9,157,433; 9,211,018RE42, 559 E; GB2378987; GB2396670; CN 221,800; ZL01129383; Others U.S. and International Patents Pending




For better protection of this product, never unfold or inflate the air mattress in temperatures below freezing. Avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care. Avoid pounding and jumping to prevent damage to the air mattress material.

Inflating and Deflating Instructions (Before inflating, Plug into AC Power outlet.)

INFLATE:




Insert plug into power outlet. Turn the control dial clockwise to the "Inflate" position to inflate the air mattress.




Upon reaching desired firmness turn the control dial counter-clockwise to the "Off" position. Make sure the switch aligns with the "Off" arrow. Air mattress is now ready for use.

DEFLATE:



Insert plug into power outlet. Turn the control dial counter-clockwise to the "Deflate" position for complete deflation.



Once air mattress is completely deflated, turn control dial clockwise to the "Off" position and place cord in the "Cord Storage Pocket".

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical furnishing, basic precautions should always be followed,including the following: **Read all instructions before using this furnishing.**

DANGER - To reduce the risk of electric shock:

1. Always unplug this furnishing from the electrical outlet before cleaning.



▲ WARNING

RISK OF SUFFOCATION

- Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months to sleep on this inflatable air mattress/air bed. Infancy can suffocate on an under-inflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.
- Children can be entrapped between the inflatable mattress and an adjacent vertical surface.
- Provide at least a shoulder width space between the inflatable mattress/air bed and adjacent vertical surfaces such as walls, dressers, or other objects.
- Always keep the inflatable mattress fully inflated when in use

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1. Unplug from outlet before putting on or taking off parts.
- 2. Close supervision is necessary when this furnishing is used by, or near children, invalids, or disabled persons.
- 3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been droppedor damaged, or dropped into water.
- 5. Keep the cord away from heated surfaces.
- 6. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair, and other similar objects.
- 7. Never drop or insert any object into any opening.
- 8. Do not use outdoors or while standing in damp area, household use only.
- 9. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.
- 10. To disconnect, turn all controls to the off position, then remove plug from outlet.
- 11. **WARNING**: Risk of Injury to Persons do not use this furnishing to support video equipment such as televisions or computer monitors.
- 12. **WARNING**: Do not use near people using or wearing medical devices.
- 13. Unplug this device from the electrical outlet when not in use or before cleaning.
- 14. Do not obstruct ventilation holes on the pump.
- 15. Double insulation-when servicing, use only identical replacement parts.
- 16. **CAUTION:** This device is operated with an electrically operated pump. The pump is thermal protected. The pump does not contain parts that can be repaired or serviced. Opening the pump case will expose you to electric shock.
- 17. DO NOT open the pump case for any reason.
- 18. DO NOT use on surfaces where heat may cause a problem.
- 19. A fire may occur if this devices touches or is covered by flammable material, including curtains, draperies, walls, etc., when in operation.
- 20. DO NOT place any flammable material such as paper, cardboard, plastic on the pump.
- 21. DO NOT operate the pump in enclosed spaces that are not well-ventilated.
- 22. DO NOT operate in the presence of explosive and/or flammable fumes.
- 23. DO NOT place any part of the pump or cord in or under water or other liquid. See instructions for cleaning.
- 24. DO NOT leave device unattended when in operation
- 25. **WARNING:** The Maximum Weight Capacity for the Queen size is 500lbs, for the Full size is 500lbs and for the Twin size is 350lbs.

SAVE THESE INSTRUCTIONS

SERVICING OF DOUBLE-INSULATED PRODUCTS

In a double-insulated product, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product, nor is a means for grounding to be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system, and is to be done only by qualified service personnel. Replacement parts for a double-insulated product must be identical to the parts they replace. A double-insulated product is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED." The symbol (square within a square) \Box is also able to be marked on the product.

Operating instructions

To reduce the risk of electric shock, this furnishing has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

WARNING: Any other servicing should be performed by an authorized service representative. A short power-supply cord is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer extension cords are available and may be used if care is exercised in their use. If a longer extension cord is used, (1) The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance, and (2) The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

DO NOT exceed 5 minutes of continuous inflation/deflation time.

In case the pump overheats due to excessive continuous inflation/deflation, the power will automatically shut-off, the power indicator light will be on. The pump will reset and begin working within 30 minutes, at which time the power indicator light will be off.

DO NOT over inflate.

DO clean air mattress with only mild soap and water.

DO NOT unfold or inflate the air mattress in temperatures below freezing.

DO avoid extensive exposure to the sun.

DO protect from contact with sharp objects and rough ground.

DO handle the pump with care.

NOTE

Air mattress material may stretch during first use and may need additional air to reach desired firmness. Air inside of the air mattress may expand and contract with varying temperatures potentially leading to reduced pressure inside of the air mattress. If this occurs, simply add more air using the built-in pump to achieve desired firmness.

For better protection of this product, never unfold or inflate the air mattress in temperatures below freezing, avoid extensive exposure to the sun and protect from contact with sharp objects and rough ground. Make sure to handle the pump with care. Avoid pounding and jumping to prevent damage to the air mattress material.

User-Maintenance instruction

WARNING: Unplug from outlet first before cleaning.

First, deflate the air mattress by following the instructions for deflation. Clean and repair the affected area thoroughly. Cut a piece of clear patch material (include in the repair kit) into a size that will cover the puncture. Apply the self-adhesive patch over the affected area by peeling off the backing and placing sticky side down on the air mattress. Rub patch to ensure adhesion. Allow four (4)hours for repair to set before attempting to inflate the air mattress.

If for any reason you are not fully satisfied, please contact our company by email at support@soundasleepproducts.com or via telephone at (347) 815-5995.

© 2016 by Somnio LLC.