



Change the way you think about time


QUASAR

INSTRUCTION MANUAL




1. How to read the time

- Quasar has 3 display modes [Number], [Pattern] & [Animation]
- You may also choose to display the time in [12hr] or [24hr] modes.
- See section 5 “How to set the time” to change your preference.
- You can illuminate the display for a short time with the EL backlight by pressing button A. This function works best at night time.



- The 3rd display mode [Animation] causes the display to transition between [Number] & [Pattern] as shown above.

2. How to read the date

- Press button B to display the date.
- The date icon  indicates that you are in date mode.
- You can illuminate the display for a short time with the EL backlight by pressing button A.
- The date can be displayed as MM/DD or DD/MM. See section 6 “How to set the date” to change your preference.
- The display will change back to time mode after a short time.

Number mode



Date icon


Pattern mode



December 5th
(12 / 05)

3. How to check the alarm time

- Press button B twice to display the alarm time.
- The alarm mode icon  indicates that you are in alarm mode.




10:20 PM (alarm on)



Pattern mode



06:30 AM (alarm on)

4. How to use the stopwatch

- Press button B three times to display the stop watch.
- The stopwatch icon  indicates that you are in stopwatch mode.
- Press button A to start & stop the timer.
- Hold button A for 3 seconds to reset the timer.
- The maximum timer is: 12hrs 59 mins & 59 secs



5. How to set the time

- When the time is displayed, press and hold button B for 3 seconds to enter setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

I. Setting the hour

- The current hour will be flashing.
- Press button A to increase the hour.
- Press button B to confirm.

08 hours

Note: In [12hr] mode the PM icon will show for PM times.



II. Setting the minutes

- The current minutes will be flashing.
- Press button A to increase the minutes.
(Hold A to increase quickly)
- Press button B to confirm.

23 minutes



III. Setting 12/24 Hour Mode

- The display will flash the current hour mode (12 or 24)
- Press button A to change the hour mode.
- Press button B confirm.




12 hour mode



24 hour mode

IV. Setting the display mode

- The current display mode will be shown.
- Press button A to change the display mode.
- Press button B to confirm & finish.



Number mode

Pattern mode



Animation mode

6. How to set the date

- When the date is displayed, press and hold button B for 3 seconds to enter date setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

I. Setting the year

- The year will flash when you are in year setting.
- Press button A to increase the year as required.
(Hold A to increase quickly)
- Press button B to confirm.

II. Setting the month

- The date mode icon will be displayed and the month will flash when you are in month setting.
- Press button A to increase the month as required.
- Press button B to confirm.

III. Setting the date

- The date mode icon will be displayed and the date will flash when you are in date setting.
- Press button A to increase the date as required.
(Hold A to increase quickly)
- Press button B to confirm.

IV. Setting the date layout

- The current date layout mode will flash.
- Press button A to change the date layout.
- Press button B to confirm & finish.



MM.DD



DD.MM

7. How to set the alarm


- When the alarm time is displayed, press and hold button B for 3 seconds to enter alarm setting mode.

*Note after 10 seconds of inactivity setting mode will deactivate

- The alarm mode icon indicates that you are in alarm setting mode.
- Press button A to turn the alarm ON or OFF. The alarm on icon will light up when the alarm is on.
- Press button B to confirm.
- The alarm hour will be flashing.
- Press button A to increase the alarm hour as required.
- Press button B to confirm.
- The alarm minutes will be flashing.
- Press button A to increase the alarm minutes as required.
- Press button B to confirm and finish.

09:30 PM (alarm on)

Note: In [12hr] mode the PM icon will show for PM times.



8. User information

I. Battery

- This watch uses a CR2025 replaceable watch battery.
- Battery lifetime will vary depending on use, but is estimated to last for at least one year.
- To maximize battery life you should limit use of the EL backlight.

II. Warranty

- This watch is covered by a 1 year warranty. This warranty does not cover water damage, accidental damage, neglect or unauthorized repair.

III. Caution

- This watch has limited water resistance. Please do not use the watch in the shower, for swimming or for other water related activities.

SPECIFICATIONS

Case Material	Silicone
Strap Material	Silicone
Case Dimensions	46 mm x 46 mm x 13 mm
Finish	Matt (silicone parts)
Maximum Fit Wrist Size	210mm (approx.)
Weight	60g
Display	LCD with EL backlight
Battery	CR2025
Water Resistance	Limited