RAM® EZ-ON/OFF™ X-Grip® Mount Assembly Instructions

Parts Index:

- A. RAM X-Grip® Holder with Quick-Release Top (QTY. 1)
- B. Quick-Release Bottom (QTY. 1)
- C. EZ-ON/OFF™ MountRubber Base (QTY. 1)
- D. EZ-ON/OFF™ Mount Tapered Rubber Base (QTY. 1)
- E. 7"Long Cable Tie (QTY. 2)
- F. 2" x 3" Neoprene Adhesive Strip (QTY. 1)
- 1. Combine (B) Quick-Release Bottom with (C) Rubber Base. For tapered handlebars, use (D) Rubber Base. Wrap (F) Neoprene Adhesive Strip around bar at desired mounting location. (F) Strip can be trimmed as needed but must contact EZ-ON/OFFTM Mount at Rubber Base and (E) Cable Ties to prevent slipping.



2. Insert (E) Zip Ties into (B) Quick-Release Bottom with perforated side facing down towards handlebars. Once desired position is reached, completely tighten zip ties and cut excess cable tie with scissors





3. To attach or remove X-Grip® from Quick-Release Base, press internal spring against rail mount (#1), and twist top portion (#2) until notches lock (to secure) or line up with openings (to release).







This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.

RAM® EZ-ON/OFF™ X-Grip® Mount Assembly Instructions

Parts Index:

- A. RAM X-Grip® Holder with Quick-Release Top (QTY. 1)
- B. Quick-Release Bottom (QTY. 1)
- C. EZ-ON/OFF™ MountRubber Base (QTY. 1)
- D. EZ-ON/OFF™ Mount Tapered Rubber Base (QTY. 1)
- E. 7"Long Cable Tie (QTY. 2)
- F. 2" x 3" Neoprene Adhesive Strip (QTY. 1)
- 1. Combine (B) Quick-Release Bottom with (C) Rubber Base. For tapered handlebars, use (D) Rubber Base. Wrap (F) Neoprene Adhesive Strip around bar at desired mounting location. (F) Strip can be trimmed as needed but must contact EZ-ON/OFFT Mount at Rubber Base and (E) Cable Ties to prevent slipping





2. Insert (E) Zip Ties into (B) Quick-Release Bottom with perforated side facing down towards handlebars. Once desired position is reached, completely tighten zip ties and cut excess cable tie with scissors



3. If using optional X-Grip® Tether, insert center hole of tether behind quick release button of X-Grip® Holder. Insert your phone into the X-Grip® Holder, and wrap corners of Tether over your phone. Once secured, stretch center hole of tether to fully wrap around the circular



3. To attach or remove X-Grip® from Quick-Release Base, press internal spring against rail mount (#1), and twist top portion (#2) until notches lock (to secure) or line up with openings (to release).

RAM Mounting Systems 8410 Dallas Ave S Seattle, WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com







This document, including images, may not be reproduced partly or fully without the expressed written consent of National Products, Inc.