

WIRELESS TEMPERATURE & HUMIDITY STATION QUICK START GUIDE



MODEL: S82967
DC: 062118

FIND FULL MANUALS, FAQs, AND MORE UNDER THE
SUPPORT TAB HERE: www.lacrossetechnology.com/S82967


POWER UP

1. Insert 2-AA batteries into your Outdoor Sensor.
2. Insert the 5 volt power cord into an outlet, then into your station. Optional: Insert 2-AA batteries for backup.
3. Adjust time and date settings on your station.
4. Once the Outdoor Sensor is reading to your station, place it outside in a shaded location.

Watch sensor mounting video: http://bit.ly/TH_SensorMounting



Outdoor Sensor
TX141TH-Bv2



Temp & Humidity Station
S82967



Pull Out
Stand

ADJUSTABLE BACKLIGHT

- Press the LIGHT button to adjust your Backlight brightness. BACKLIGHT and your brightness level will show (OFF,1, 2, 3, 4).



SETTINGS

1. Hold the SET button to enter the Settings Menu.
2. Press the + or - button to adjust the values. Hold to adjust quickly.
3. Press the SET button to confirm and move to the next item.
4. Press the LIGHT button to exit.

Settings Menu Order:

- Language (English, Spanish, French)
- Beep ON/OFF
- 12/24 Hour
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit or Celsius

Note: Your weekday will set automatically after year, month, and date are set.

AUTO DIM BACKLIGHT

1. Hold the AUTO DIM button to set Auto Dim Start and Stop times.
2. Use the + or - button to turn the Auto Dim feature ON. Press the AUTO DIM button to confirm and move to next item.
3. START TIME will flash. Use the + or - buttons to select your Auto Dimmer's starting hour. Press the AUTO DIM button to confirm and move to next item.
4. STOP TIME will flash. Use the + or - buttons to select your Auto Dimmer's ending hour. Press the AUTO DIM button to confirm.



OTHER BUTTON FUNCTIONS

Hold ALERTS button: To set Temperature and Humidity Alerts.

- Use + or - buttons to arm or disarm alert.
- Press Alerts button to confirm and set armed alert value.
- Use + or - buttons to adjust Alert Value.

Hold SENSOR button: To search for Outdoor Sensor.

Press TEMP button: To view HI & LO Temp and Humidity records.

Keep pressing TEMP to view Heat Index & Dew Point readings.

Hold LIGHT & ALERTS buttons together: Factory reset station.

LOW BATTERY INDICATORS

- When Battery Indicator shows next to the word Outdoor, replace batteries in your Outdoor Sensor.
- When Battery Indicator shows next to your Time, replace batteries in your Station.

SENSOR WEATHER SHIELD-NOT INCLUDED

The Sensor Weather Shield is designed to protect your outdoor sensor from rain and snow. This shield will offer limited protection from the sun's heat.

Purchase at: <http://bit.ly/925-1418>



SPECIFICATIONS

Indoor:

Temperature Range: 32°F to 99°F (0°C to 37°C)

Humidity Range: 10% to 99% RH

Outdoor:

Temperature Range: -40°F to 140°F (-40°C to 60°C)

Humidity Range: 10% to 99% RH

Transmission Range: over 300 feet (91 meters) in open air RF 433MHz

Power Requirements:

S82967: AC6: GPU280500150WA00 (required)

Optional: 2 "AA" LR6 Batteries (not included)

TX141TH-Bv2: 2 "AA" LR6 Batteries (not included)

Battery Life:

S82967: over 24 months with reputable batteries

TX141TH-Bv2: over 24 months with reputable batteries

Dimensions:

S82967: 3.77" L x 1.14" W x 7.01" H (9.6cm L x 2.89cm W x 17.82cm H)

TX141TH-Bv2: 1.57" L x 0.82" W x 5.11" H (3.98cm L x 2.08cm W x 12.98cm H)

WE'RE HERE TO HELP!

Our knowledgeable customer support team is available:

Monday-Friday, 8am-6pm CST. Phone: 1.855.605.6888

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

For Full Warranty Details, Visit: www.lacrossetechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not to be used for an extended period.
- Promptly remove expired batteries.

CANADA STATEMENT

This device complies with CNR Industry Canada license -exempt devices. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Increase separation between equipment & receiver.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:


- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

 **WARNING:** This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov