


Dolly's Pram Assembly Instructions

Parts




Pre-Assembly Information

- Start by familiarizing yourself with the parts above. This will make it easier to know how it all fits together.
- You will need a Phillips Head Screwdriver and a few drops of glue for the button caps.
- Locate a flat, level work surface, like a hardwood floor or a large table.
- Do not overtighten screws as you can strip out the material. This is less likely to happen with a screwdriver, so take care when using a drill or screw gun.
- Remember that this product is made of wood, a natural, living material. As such, humidity and dryness in the air can influence the product. Though it has been produced with the greatest care and precision possible you may experience minor variation in fit and finish.
- Read instructions completely before beginning so that you fully understand the process. It's easy and fun to do, but you'll feel more confident if you know what the next step is before you get there.


Caring for the Dolly's Pram

- The pram is made of natural wood that has been finished with Tried & True Danish Oil, a polymerized linseed oil, which is food safe and non-toxic. To maintain the satin finish, we recommend reapplying this oil periodically, as you notice the wood drying out. Please visit <http://www.triedandtruewoodfinish.com> to find a retailer.
- Should the wood become discolored, we recommend cleaning it with Murphy's Oil Soap. If stubborn stains persist, use a fine green scrubbie (such as used on pots and pans) and rub lightly following the grain of the wood. Then apply a thin coat of the Danish Oil, according to the instructions provided.


Assembly




1. Insert one End Board into the front groove on the Right Side ensuring the rounded edge is flush with the top of the groove.




2. Secure the End Board to the right Side with a Flat Head Screw.




3. Insert the other End Board, with threaded insert, into the rear groove flush with the top of the groove. Secure End Board using a Flat Head Screw.




4. Place the Lower Foot Board underneath the End Board, secure using a Wood Screw.




5. Place Lower Head Board into horizontal groove securing with two Wood Screws.




6. Place the Middle Boards into the remaining horizontal groove and secure with two Wood Screws.




7. Fully seat Left Side on top of Pram assembly. Secure End boards with Flat Head Screws and Middle and lower Boards with Wood Screws.




8. On a sturdy hard surface place Axle End Cap on the end of Axle, seat with a hammer strike. Slide a wheel (smooth side out) onto Axle.




9. Slide Axle through pre-drilled holes in Pram, turn over and slide opposite wheel onto the axle (smooth side out). Secure Axle End Cap with a hammer strike. Repeat steps 8 and 9 for other Axle.



10. On a flat Level surface place Handle into pre-drilled holes in the Handle Arms. Ensure the assembly is square and secure using Wood Screws.



11. Place handle assembly into the grooves in the Pram and desired handle height. Lower position is 21" and upper 24" from the ground. Secure with two Chicago Bolts.



12. Insert Button Caps into screw holes in by placing a dab of glue on their ends and pressing down or lightly tapping with a hammer.

Congratulations on a job well done!
We hope you and your child enjoy
years of play with your new
Dolly's Pram

