


Sam's Stable Assembly Instructions

Parts




Pre-Assembly Information

- Start by familiarizing yourself with the parts above. This will make it easier to know how it all fits together.
- You will need Phillips Head Screwdriver and a few drops of glue for the button caps.
- Locate a flat, level work surface, like a hardwood floor or a large table.
- Pine is a soft wood, do not overtighten screws as you can strip out the material. This is less likely to happen with a screwdriver, so take care when using a drill or screw gun.
- Remember that this product is made of wood, a natural, living material. As such, humidity and dryness in the air can influence the product. Though it has been produced with the greatest care and precision possible you may experience minor variation in fit and finish.
- Read instructions completely before beginning so that you fully understand the process. It's easy and fun to do, but you'll feel more confident if you know what the next step is before you get there.


Caring for Sam's Stable

- The stable is made of natural wood that has been finished with Tried & True Danish Oil, a polymerized linseed oil, which is food safe and non-toxic. To maintain the satin finish, we recommend reapplying this oil periodically, as you notice the wood drying out. Please visit <http://www.triedandtruewoodfinish.com> to find a retailer.
- Should the wood become discolored, we recommend cleaning it with Murphy's Oil Soap. If stubborn stains persist, use a fine green scrubbie (such as used on pots and pans) and rub lightly following the grain of the wood. Then apply a thin coat of the Danish Oil, according to the instructions provided.


Assembly




1. Insert the Stable Wall into Base with Stalls oriented as shown, with wall flush against stalls.




2. Drive two Wood Screws into Stable Wall , securing it to Base with Stalls as shown.




3. Drive Wood Screw through Stable Wall into Base with Stalls.




4. Insert the Stable Doors into Base with Stalls oriented as shown.




5. Drive two Wood Screws into Stable Doors, securing it to Base with Stalls as shown.




4. Slide Loft Floor into slots in Stable Wall and Stable Doors.




7. Secure Loft Floor by driving four Wood Screws (two at either end) into it.




8. Position Front Roof as shown with slots fully seated on Walls.




9. Align Front Roof as indicated by arrow, so that base of slot aligns with top of Walls.



10. Drive four Wood Screws into Front Roof to secure it.



11. Seat slots of Back Roof on Walls. Slide up and into slot in Front Roof. Secure it with four Wood Screws.



12. Insert Button Caps into screw holes by placing a dab of glue on their ends and pressing down or lightly tapping with a hammer.

Congratulations on a Job Well Done!
We Hope You and Your Child Enjoy
Years of Play with Your New
Sam's Stable

