What Do I Do If My GO! Loses The Connection With My Smart Phone?

The communication range between your GO! And your smart phone is approximately 30 feet. Beyond this range your GO! May lose the connection with your smart phone.

If your GO! Loses connection, this is the easiest way to re-establish it:

1. On your smart phone:

Sign out of the Soleus GO! APP



2. On your GO!:

Press the 'o' button to wake up the display.

If the Bluetooth on your GO! Is ON, press-and-hold the 'o' button until "BLE OFF" starts blinking. This will turn the Bluetooth off.

With the Bluetooth on your GO! OFF, press-and-hold the 'o' button until "SYNC DATA" starts blinking and then scrolls.

