

FIXED SHORT WALKER



Application Instructions

1. Place foot and leg inside soft liner with heel firmly back. Pads may be inserted at either side of the ankle or at the heel if there is extra space.
2. Close the liner tightly, left to right, securing hook and loop.
3. Position heel of the foot against the rocker boot. Brace uprights should be positioned midline over the ankle.
4. Press the uprights securely against the liner. If there is a slight overlap, position the upright under the overlap permitting removal of the brace without changing the position of the upright.
5. Slide the sleeves from the uprights and press uprights firmly against the liner.
6. Fasten the two lower straps through the D-rings securing with hook and loop.
7. An optional padded strap is provided for additional padding at the ankle if desired.
8. Wrap the detachable outer liner around the uprights fastening hook and loop. Secure liner with closure strap.