



DELANO BASKET

Installation Manual



REQUIRED TOOLS:



- *3mm Hex Wrench*
- *4mm Hex Wrench*
- *5mm Hex Wrench*
- *8mm Box Wrench*
- *10mm Box Wrench*

[SEE FIGURE 1.]

INCLUDED HARDWARE:

- *Basket Braces (2)*
- *Mounting Bracket*
- *M4 x 12mm bolts (4)*
- *M5 x 20mm bolts (2)*
- *M5 x 15mm bolts (4)*
- *M4 Locknuts (2)*
- *M5 Locknuts (4)*
- *Bracket Spacers (2)*
- *M4 Washers (6)*
- *M5 Washers (4)*

[SEE FIGURE 3.]





STEP 1

Remove slat beneath the cup holder using the 3mm Hex Wrench and 8mm Box Wrench.

Set slat aside.



[SEE FIGURE 4.]

STEP 2

Attach Basket Braces with M5 x 15mm bolts, M5 washer, and M5 Locknut using the 5mm Hex Wrench and 10mm Box Wrench. Do not tighten down completely.

**Note the braces are not symmetrical. The right (bicycle drive side) brace is stamped 'R' facing out when mounted and left is stamped 'L' facing out when mounted.*

[SEE FIGURE 5.]




The braces are mounted on the inside of the basket mounting rail.

[SEE FIGURE 6.]

Both braces are mounted loosely and can slide forward and back on the basket.

[SEE FIGURE 7.]






FIGURE 8.

STEP 3

Attach Mounting Bracket with M4 x 12mm bolts, M4 washers, and M4 Locknuts. The bracket angle faced down. Do not tighten down completely.

[SEE FIGURE 8.]

If necessary, use included spacers and M5 x 20mm to ensure basket sits level on smaller front forks. Do not tighten down completely.

[SEE FIGURE 9.]




FIGURE 9.



FIGURE 10.

STEP 4

Slide Mounting Bracket onto threaded brake bolt, or separate bolt, or separate bolt approx. 45mm in length (not included), if there is no front brake.

[SEE FIGURE 10.]

Tighten down brake with 5mm Hex Wrench. Tighten separate bolt with locknut if there is no front brake.

[SEE FIGURE 11.]



FIGURE 11.



STEP 5

Mount lower brace flange using M4 x 12mm bolts and M4 washers into the fork drop out braze-ons. Tighten bolts with 4mm Hex Wrench.

[SEE FIGURE 11.]

STEP 6

Slide basket along mounting bracket toward, or away from the front of the bike. Tighten down bracket completely once basket is level using 4mm Hex Wrench and 8mm Box Wrench.

[SEE FIGURE 8.]

STEP 7

Slide basket along mounted braces to desired distance from front of the bike. Tighten down M5 x 15mm bolts and M5 Locknuts completely using M5 Hex Wrench and 10mm Box Wrench.

[SEE FIGURE 6.]

STEP 8

Replace slat beneath the cup holder using the 3mm Hex Wrench and 8mm Box Wrench. Tighten down all slats completely.

[SEE FIGURE 12.]



STEP 9

Double-check all nuts and bolts to ensure they are tight.

Delano Basket is installed.

[SEE FIGURE 13.]

