



Watch video help at WINDCATCHERGEAR.COM/HELP





How to Inflate & Close

Do NOT bend or kink along edge during inflation

1. Unroll the Air Pad and make sure the **black-side is facing up**.


2. Make sure the **Deflation Flap is pushed inside** the Air Pad.


 Bending the Windcatcher at the edge of the Air Pad will stop air from entering. If needed, bend the Air Pad closer to its middle or stand up to inflate.




3. **Take a deep breath** and then **strongly blow** into the Windcatcher.


4. Blow into the Windcatcher **4 to 7 more times** or till mostly full.

 Leave **at least 4 inches** (about the width of your hand) between your mouth and the Windcatcher.





5. Strongly blow directly into the Windcatcher **one more time**; this time **with no space** between you and the Windcatcher.

 Did it take you more than 9 breaths to inflate? If so, please watch the video instructions at windcatchergear.com/help




6. **Tightly roll up** the Windcatcher all the way to the Air Pad.

 To prevent any air from leaking out, be sure to roll it very tightly. If you have difficulty rolling it up, use the valve on the corner of the Air Pad to let out a little air.



7. **Pull the straps all the way through** the loop and secure with the last Velcro section.


8. **Flip the Air Pad over**, so that you can lay on top of the red-side.



How to Deflate & Pack up

1. Remove the straps and allow the Windcatcher to unroll.

2. Reach inside the Windcatcher and **pull out the Deflation Flap** by grabbing the black pull tab.



3. With the **red-side facing up**, fold the Air Pad into thirds.

4. Roll the Air Pad towards the Windcatcher. Keep rolling so the Windcatcher wraps around the outside of the roll.

5. Secure roll with Velcro straps.



For helpful videos and tips visit www.windcatchergear.com/help