NIWALKER®

N01S充电式LED手电采用　　　　灯珠，最大流明可达1800流明，最大射程可达1100米

规格参数

机械参数							
LED灯珠	光镜	光杯	工作电压	材质	表面处理	尺寸	重量
	防刮玻璃镜片		2.8V-4.3V	AL T6061-T6		57mm*26.4mm*126mm	129g
配件	*1	O *1	USB-C	NIWALKER 18650	*1		

ANSI/NEMA FL1参数						
	照明模式					
	极亮档	高亮档	中亮档	中低亮档	低亮档	月光档
档位亮度	1800流明	1280流明	468流明	80流明	15流明	3流明
续航时间	1分钟+1小时30分钟	1小时40分钟	4小时5分钟	21小时	150小时	500小时
最大射程	1100 米					
最大光强	1210000 坎德拉					
防跌落等级	1.5米					
防水等级	IPX–7					

注：上述参数只是一个近似值，以18650 3000mAh电池在实验环境中测试所得，可能会随着手电，电池和使用环境而发生变化。

电量指示灯

电量等级	0%	1 – 10%	11 – 30%	31 – 100%
LED状态	无指示	红灯		蓝灯常亮

操作说明

注意：请在使用前拧紧灯头和灯尾再进行后续操作。
手电开关
轻触侧开关即可点亮手电
模式切换
月光档：关机状态下，长按进入月光档。
普通档：关机状态下，单击进入普通档，在普通档下长按按键可以换档（5
极亮档：快速双击进入极亮档
爆闪档：快速三击进入爆闪档，
锁机功能：关机状态下，快速四击锁机，成功后灯会闪烁3下。再次快速四击解锁。
　　　　　　　7　　　5　　　　　　　　　　　（　　　　　　　　烁3
　　　　　　　　　　　　　　　　　　　3.7V）.

档位记忆功能：记忆关闭前的普通档位

警示
1. 手电亮度高，请勿直视发光体，以免造成视力损伤。
2. 请远离儿童防止其误食。
3. 为了保护电池，电路板以及LED灯珠，我们建议操作极亮模式不要

充电功能说明

TYPE-C，　　　5V 2A

NO1S is an efficient Type C rechargeable LED flashlight with high performace long shot LED, the max output is up to 1800lm and the max beam distance of 1100meters.

Specifications

Technical Parameters							
LED	Lens	Reflector	Working Voltage	Material	Surface Finish	Dimension	Weight
Ultra High Intensity LED	Toughened uttra-clear glass lens	Aluminium Electroplated	2.8V-4.3V	AL T6061–T6	White finishing	57*26.4*126mm	129g
Accessories	Lanyard *1, Spare O-ring *1, , USB-C Charging Cord *1 Niwalker18650 3000mAh battery *1(Optional)						

ANSI/NEMA FL1 Parameters						
	General Mode					
	Turbo	High	Medium	Low 1	Low 2	Firefly
Output	1800 lumens	1280 lumens	468 lumens	80 lumens	15 lumens	3 lumens
Run time	1min+1hr30mins	1hr40mins	4hrs5mins	21 hrs	150hrs	500 hrs
Distance	1100 meters (max.)					
Intensity	1210000 cd (max.)					
Impact Resistance	1.5 meter					
Waterproof	IPX-7					

Notes: The above parameters tested by one 3000mAh 18650 battery are approximate and may vary between lights, batteries and environment.

Indicator

Power Capacity	0%	1 - 10%	11 - 30%	31 - 100%
Indicator	Off	Red flash	Red	Blue

Operation

CAUTION :Please screw down the light head and tail cap tightly before use.
Turn ON/OFF
Press the side switch to turn the light on/off.
Change Modes
1.Moonlight: When the light is off, long press the side switch to get firefly mode,one click to OFF.
2.Stepped Ramping: when the light is on, long press the side switch to cycle 5 different brightness,one click to OFF. The light will turn on in the last mode accessed.
3.Turbe Mode: Double click to turn to turbo from any mode, one click to OFF.
4.Strobe Mode: Triple click to turn to strobe,one lick to OFF.
5.Lockout Function:When the light is off, press the switch four times quickly to lock the light. It will flash 3 times while locked. Click the switch four times quickly to unlock.
6.Battery Power Monitor:when the light is off, five clicks to activate battery power monitor. The flashlight will flash to indicate the corresponding voltage value. Eg: The flashlight flashes slowly 3times, and then flashes quickly 7 times, that means the volt is 3.7V at this moment. One click to OFF.

Warnings
1.Flashlights are high-intensity lighting devices capable of causing eye damage or other harms, so please avoid shining our light directly into anyone's eyes.
2. Please keep flashlights away from children.
3. To protect the battery, driver circuit and LED, we Do NOT recommend you run the light at max mode more than ten minutes.

Rechargeable Funciton

Battery Voltage Indicator
Battery charging indicator

USB-C charing, please use 5V 2A Charger to charing.
When battery is charing, the indicator under button will be red light. After battery has been fully charged, the indicator will be blue light.