

How to adjust your link strap

- 01** Open the folding clasp and place your link strap face down on a table. Now you will see small arrow markings on some links. These are marking the links that you can potentially remove.
- 02** Determine by how many links you want to shorten your strap. Note: We recommend shortening the strap evenly (mirrored) on each side. Therefore, carefully choose how many links you want to remove on each side.
- 03** Take the provided screwing tool and unscrew it until the screwing piece is tight enough to stay in the tool – not more than that.
- 04** Insert the metal strap straight into the screwing tool, so that the tip of the screwing piece meets the hole of the link marked with an arrow.
- 05** Turn the screw back in as far as possible to get the metal pin of the link.
- 06** Unscrew the screw, remove the strap from the holder and remove the metal pin. Keep it safe, in case you want to extend the strap again.

→

How to adjust your link strap

- 07** Repeat the procedure (from point 03) at the arrow marking of the link you want to remove.
- 08** Place the "separated" metal strap loosely back together on the table. Also: Front down on the table.
- 09** Insert a metal pin with the blunt side (rounded side) into the hole of the link (opposite of the arrow mark), which is to be reattached.
- 10** You won't be able to insert the pin completely with your hands. Therefore, choose any hard object (e.g. the screwing tool) to push the metal pin back into the link with a little pressure.
- 11** You made it! If necessary, repeat the procedure on the other side of the strap.