

PROJAM

Assembly Manual



v1.0

JumpFlex

play for life

 facebook.com/jumpflex

 Share your fun on instagram #Jumpflex



FIND JUMPFLEX

WORLDWIDE




Australia

 1800 586 735

jumpflex.com.au




New Zealand

 0800 586 735

jumpflex.co.nz



USA

 1866 305 7238

jumpflex.com



Canada

 1866 305 7238

jumpflex.ca



UK

 0330 010 4301

jumpflex.co.uk



Warning: Read all assembly, installation, care, maintenance and use instructions in the manual prior to assembling and using this Jumpflex accessory.



These products are for personal use only by 1 person aged 6 years and older, for outdoor use.

Warning: For domestic use only. Adult assembly required.

Risk Warning: The use of this product involves a significant risk of participants suffering personal injury including the possibility of serious injuries, permanent disability or death. All participants who engage in activities with the product do so at their own risk.

PROJAM | Assembly Instructions

Trampoline | Parts List



	Part Type	Quantity
1	PJ-Connect	1
2	PJ-Bolt	1
3	PJ-Top	1
4	PJ-Fibre Rods	6
5	PJ-Backboard + Hoop	1
6	PJ-Bottom	1
7	PJ-Sleeve	1

Step | 1

Separate the 6 fibreglass rods so that they are in matching pairs.



Step | 2

Select the fibreglass rod with a silver connector at one end and **no** rubber cap at the other end.

Now select the PJ-Connect (the square black piece with the sewn cross) and feed the rods through the cross piece, as shown.



Step | 3

Unfold the Backboard and Hoop component and lay it face down, so the green hoop is facing towards the ground.

Lay the assembled cross piece in the middle of the backboard and position the other rods, as shown.



Tip: Position the assembled cross piece down in the centre of the backboard, so that the Velcro fold is facing upwards.



Step | 4

Select the 2 fibreglass rods **without** the silver metal connector. Feed the end that does not have a rubber cap through the small loop tag on the backboard and then insert the other end (with the rubber cap) into the corner pocket of the backboard.



Now connect these 2 fibre rods into the fibreglass rods on the cross piece component.

You will have 2 x fibreglass rods remaining each with a silver metal connector and rubber end cap.

Insert one of these into the top corner and connect the other end to the cross piece assembly.



Step | 5

⚠ Important Note

To connect final fibreglass rod, first insert the end into the silver metal connector, wrap your arm under the rod and grip it as shown. This will give you leverage to bend it into place and insert it into the corner tab of the backboard.

Note: Please take caution as the fibre rods are under tension.



PROJAM | Assembly Instructions

Step | 6

Select the PJ-Top, open the Velcro flap in the centre of the connected rods, and slide the metal plate into place.

Make sure to slide the plate all the way inside the pocket, and that the Velcro flap is securely closed.

PJ-TOP



Step | 7

Set the Assembled backboard and hoop aside.

Walk around to the back of the Trampoline and find the net pocket that has a small slit hole sewn into the top, as shown. It will be on the opposite side of the zip. Remove this pocket and take down the Safety Net Pole.



PROJAM | Assembly Instructions

Step | 8

After removing this pole from the net, detach the pole from the trampoline.

Remove the black sleeve off of the Safety Net Pole.



Step | 9

Using a Flat-head screwdriver, or similar device, gently remove the plastic plug that is inserted at the top of the Safety Net Pole.



PROJAM | Assembly Instructions

Step | 10

Select the PJ-Bottom that fits into the top of your Safety Net Pole and insert this metal piece into the top of the Safety Net Pole.



Step | 11

Now select the provided PJ-Sleeve that came with your Projam accessory.

Slide the sleeve over the safety net pole and push the metal connector through the hole at the end of the sleeve. This will replace the previous sleeve.



Step | 12

Before reconnecting the modified Safety Net Pole back onto the Trampoline, match the PJ-Top against the PJ-Bottom to make sure that the pieces are facing the correct direction to interlock. The ripples should interlock.



PROJAM | Assembly Instructions

Step | 13

After you have reconnected the Safety Net Pole, re-insert the top of the pole into the net pocket and feed the metal joint bracket through the net pocket slit.



Step | 14

Standing inside the trampoline, align the backboard up with the metal connector on the safety net pole. Connect the backboard to the safety net pole using the provided nut and bolt (PJ-Bolt).



PJ-BOLT



Step | 15

Fasten the nut and bolt securely, making sure the backboard is positioned vertically level.



PROJAM | Assembly Instructions

Step | 16

Double check that the backboard is sitting level with the top of the net. Now pull the plastic clips at the bottom of each corner of the backboard down and clip these to the safety net weave.



Step | 17

Adjust the straps of the hoop so the hoop is sitting level.

You can tidy the excess webbing on the straps by looping them back through the buckle. Test the hoop by pulling it down, it should pop back into the level position. If it doesn't, adjust the hoop straps until it does.



Step | 18

Pump up the provided ball and you are now ready for some extreme air slam dunks!



Step | 19

Congratulations!

You have finished the assembly of your Jumpflex Projam Backboard.



Share your awesome dunks with us on instagram [#Jumpflex](#)



Play for Life

