

PROJAM™ UK FLEX Series

Assembly Manual

SCAN ME



Watch Assembly Video





Warning: Read all assembly, installation, care maintenance and usage instructions in the manual prior to assembling and using the Jumpflex® product.

These products are for personal use only by one person aged 6 years and older.

These products are for outdoor use only.








Warning: For domestic use only. Adult assembly required.

Risk Warning: The use of this product involves a significant risk of participants suffering personal injury, including the possibility of serious injuries, permanent disability or death. All participants who engage in activities with the product do so at their own risk.

Contents

PROJAM™ Parts List	4
Setup	5
Assembly Instructions	6

PROJAM™ Parts List

#	Part	Description	Quantity
1		Backboard and Hoop	1
2		Fiberglass Rod Connector	4
3		Fiberglass Rod End	4
4		High Mount Cross Bracket	1
5		Basketball	1
6		Ball Pump	1
7		PROJAM™ Adapter	1

Setup

High Mount


Ideal for big jumpers and big air slam dunks!



High Mount Assembly Instructions

01



Lay the **Backboard and Hoop (1)** face down.









Join together 4x **Fibreglass Rod Connectors (2)**
and 4 x **Fibreglass Rod Ends (3)**.

Thread one connected fibreglass rod assembly through the webbing loop on the backboard and into the bottom corner pocket.




Repeat step 03 on the other side.







Insert each end of the fiberglass rods into the **High Mount Cross Bracket (4)** as shown.

Thread another fibreglass rod assembly into the **High Mount Cross Bracket (4)** and insert the other end into the corner pocket.







Repeat step 6 on the other side.








- ! Pull the corner of the backboard away from the center and pre-bend the fiberglass rod to create enough space to insert the rod into the corner pocket.

Attaching to your Jumpflex® Trampoline


Select any of the enclosure net poles on your trampoline where you would like to position the PROJAM™. Unclip the fibreglass net ring pole and remove the plastic hook from the upper net pole.




Attach the PROJAM™ adapter by clipping it onto the upper net pole. Clip the fibreglass net ring pole into the plastic hook. Remove the top screw cap and fasten the PROJAM™ bracket to the adapter.



Adjust the hoop straps to ensure the hoop is sitting horizontally.





Use the provided **Ball Pump (9)** to inflate the **Basketball (8)**.

Enjoy!

play for life



USA

ph. 1866 305 7238
www.jumpflex.com

Canada

ph. 1866 305 7238
www.jumpflex.ca

UK

ph. 0330 010 4301
www.jumpflex.co.uk

New Zealand

ph. 0800 586 735
www.jumpflex.co.nz

Australia

ph. 1800 586 735
www.jumpflex.com.au