

PROJAM™ Hero Series

Assembly Manual

SCAN ME



Watch Assembly Video





Warning: Read all assembly, installation, care maintenance and usage instructions in the manual prior to assembling and using the Jumpflex® product.

These products are for personal use only by one person aged 6 years and older.

These products are for outdoor use only.










Warning: For domestic use only. Adult assembly required.

Risk Warning: The use of this product involves a significant risk of participants suffering personal injury, including the possibility of serious injuries, permanent disability or death. All participants who engage in activities with the product do so at their own risk.

Contents

PROJAM™ Parts List	4
Setup Options	5
High Mount Assembly Instructions	6
Low Mount Assembly Instructions	17

PROJAM™ Parts List

#	Part	Description	Quantity
1		Backboard and Hoop	1
2		Fiberglass Rod Connector	4
3		Fiberglass Rod End	4
4		High Mount Cross Bracket	1
5		Low Mount Cross Bracket	1
6		Low Mount Net Connector	2
7		Low Mount Pole Strap	2
8		Basketball	1
9		Ball Pump	1

Setup Options


High Mount

High mount option, ideal for big jumpers and big air slam dunks! Please follow assembly instructions on page 6.



Low Mount


Low mount option, compatible with SMARTSHADE™ sun cover and great for little jumpers. Please follow assembly instructions on page 17.



High Mount Assembly Instructions

01



Lay the **Backboard and Hoop (1)** face down.









Join together 4x **Fibreglass Rod Connectors (2)** and 4 x **Fibreglass Rod Ends (3)**.

Thread one connected fibreglass rod assembly through the webbing loop on the backboard and into the bottom corner pocket.




Repeat step 03 on the other side.







Insert each end of the fiberglass rods into the **High Mount Cross Bracket (4)** as shown.

Thread another fibreglass rod assembly into the **High Mount Cross Bracket (4)** and insert the other end into the corner pocket.






Repeat step 6 on the other side.





- ! Pull the corner of the backboard away from the center and pre-bend the fiberglass rod to create enough space to insert the rod into the corner pocket.

Attaching to your Jumpflex® Trampoline


Select any of the enclosure net poles on your Jumpflex® Hero Series Trampoline where you would like to position the PROJAM™. Remove the top screw cap on the selected net pole, place the assembled **High Mount Cross Bracket (5)** over the thread and re-screw the top screw cap in place.




Clip the backboard carabiners through the safety net to secure the bottom corners in place.



Adjust the hoop straps to ensure the hoop is sitting horizontally.






Use the provided **Ball Pump (9)** to inflate the **Basketball (8)**.

Low Mount Assembly Instructions

01



Lay the **Backboard and Hoop (1)** face down.







Join together 4x **Fibreglass Rod Connectors (2)**
and 4x **Fibreglass Rod Ends (3)**.



Thread one connected fibreglass rod assembly through the webbing loop on the backboard and into the bottom corner pocket.




Repeat step 03 on the other side.




Insert each end of the fiberglass rod assembly into the **Low Mount Cross Bracket (5)** as shown.







Thread 1x fibreglass rod assembly through 1x **Low Mount Pole Strap (7)** as shown.

Connect together the **Fibreglass Rod Connector (2)** into 1x **Fibreglass Rod End (3)**, and thread into the **Low Mount Cross Bracket (5)**. Insert the other end into the corner pocket.



Repeat step 07 on the other side.




08




! Pull the corner of the backboard away from the center and pre-bend the fiberglass rod to create enough space to insert the rod into the corner pocket.


Attaching to your Jumpflex® Trampoline

Select any two enclosure net poles on your Jumpflex® Hero Series Trampoline where you would like to position the PROJAM™. Remove the top screw caps on the selected net poles, place the assembled **Low Mount Pole Straps (7)** over the thread and re-screw the top screw caps.





From the outside of the net enclosure, attach the hook end of the **Low Mount Net Connector (6)** through net and around the bottom corner of the fiberglass rod assembly.







Strap the webbing length around the enclosure pole and re-attach onto the buckle.

Repeat steps 11 and 12 on the other side, tighten each webbing strap so the PROJAM™ is sitting vertically level.



Adjust the hoop straps to ensure the hoop is sitting horizontally.





Use the provided **Ball Pump (9)** to inflate the **Basketball (8)**.

Enjoy!

play for life



USA

ph. 1866 305 7238
www.jumpflex.com

Canada

ph. 1866 305 7238
www.jumpflex.ca

UK

ph. 0330 010 4301
www.jumpflex.co.uk

New Zealand

ph. 0800 586 735
www.jumpflex.co.nz

Australia

ph. 1800 586 735
www.jumpflex.com.au